

NETWORK 1275 Danner Dr Tel:330-562-7070 TECHNOLOGIES Aurora, OH 44202 Fax:330-562-1999 INCORPORATED www.networktechinc.com

XTENDEX® Series

ST-IPHD-POELC-V4 Low-Cost HDMI Over Gigabit IP Extender with IR and Power over Ethernet (POE)

Installation and Operation Manual



TRADEMARK

XTENDEX and the NTI logo are registered trademarks of Network Technologies Inc in the U.S. and other countries. All other brand names and trademarks or registered trademarks are the property of their respective owners.

COPYRIGHT

Copyright © 2021 by Network Technologies Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Network Technologies Inc, 1275 Danner Drive, Aurora, Ohio 44202.

CHANGES

The material in this guide is for information only and is subject to change without notice. Network Technologies Inc reserves the right to make changes in the product design without reservation and without notification to its users.

TABLE OF CONTENTS

Introduction	1
MATERIALS	2
Connectors and LEDs	3
Installation	4
Point to Point Connection	4
Daisy-Chained Switches	5
Point to Many Connection	5
Many to Many Connection	6
Many-to-Many Configuration of ST-IPHD-POELC-V4 Extenders	7
Technical Specifications	11
Troubleshooting	12
Warranty Information	12

TABLE OF FIGURES

Figure 1-Point to point connection- directly	.4
Figure 2-Point to point connection-through switch	4
Figure 3-Daisy-Chained Switches	5
Figure 4-Point to many connection	5
Figure 5-Many to many connection	6

INTRODUCTION

The XTENDEX® Low-Cost HDMI Over Gigabit IP Extender with IR and POE multicasts digital video and audio signals to one or more receivers up to 394 feet away over a 1000 Base-T Gigabit Network connected with CAT6/6a/7 cable.

Each Low-Cost HDMI Over Gigabit IP Extender with IR and POE consists of a local unit that connects to an HDMI source, and a remote unit that connects to an HDMI display. The local and remote units can be connected together for a Point-to-Point connection via CATx or a Point-to-Many connection via a network switch. Support for multiple transmitters requires a managed network switch.

Features

- Supports HDTV resolutions to 1080p.
 - Extend up to 394 feet (120 meters) with CAT6/6a/7 cable.
 - Extend up to 328 feet (100 meters) with CAT5e cable.
- Cascade network switches to extend the length long distances.
 - Up to three switches can be cascaded.
 - The max cable length between the first switch/transmitter and the last switch/receiver is 1,575 feet (480 meters) for CAT6/6a/7 or 1,312 feet (400 meters) for CAT5e cables.
 - The max cable lengths between switches is switch dependent, but 394 feet (120 meters) is typical with CAT6/6a/7 cable.
- Power over Ethernet (PoE) power supply not required at the local or remote unit.
- Ideal solution for digital signage applications.
- Broadcast real-time HDMI video and audio signals to multiple display locations with a managed or unmanaged (also known as non-managed) network switch.
- Transmits an HDMI signal over one CATx cable.
- Full Infrared Remote (IR) control of HDMI source from remote HDTV using existing source remote control.
- Plug-and-Play installation allows receivers to find the transmitters automatically on the same subnet. (Network configuration may be required for managed network switch.)
- Easily expandable. Add remote units as you add monitors.
- Inexpensive CATx cable replaces bulky video cables.
- Supports 1000 Base-T Ethernet connection.
- Built in default EDID table.
- HDMI 1.4 and HDCP 1.4 compliant.
- Support for multiple transmitters requires a managed network switch with VLAN support. Standard LAN switches can only support one transmitter.
 - o The managed switch must support port-based IEEE 802.1Q VLAN.
 - Each VLAN acts as a separate HDMI Over IP Channel on the network.
 - Each VLAN channel supports one transmitter.
 - Number of local and remote units that can be used is dependent on the backplane bandwidth of the switch.
- For a point-to-many connection, a standalone network with an unmanaged network switch, hub, or router can be used instead of a managed network switch.
 - Up to 253 receivers supported.
 - It is not recommended to use any other network devices on this standalone network as it may cause a degradation in performance.
- Local and remote units must be in the same LAN. The units do not support WAN connections.

NOTE: ST-IPHD-POELC-V4 models are NOT compatible with ST-IPHD-POELC(-CLR) models due to different chipsets being used.

MATERIALS

Materials supplied with this kit:

- NTI XTENDEX ST-IPHD-POELC-V4 Local and Remote Unit
- URL slip with path to this manual
- IR-EMITTER with 42.5" (1080mm) cable
- IR-RECEIVER with 40" (1015mm) cable

-OR-

- NTI XTENDEX ST-IPHD-R-POELC-V4 Remote Unit only
- URL slip with path to this manual
- IR-RECEIVER with 40" (1015mm) cable

Additional materials may be required but are not supplied:

- CAT5e solid/stranded UTP ; 6/6a solid UTP; CAT7 solid STP (CATx) twisted-pair cables for TIA/EIA-568B wiring terminated with standard RJ45 connectors wired straight thru- pin 1 to pin 1, etc.
- HDMI male-male cable to connect a HDMI source or display (Order NTI # HD-xx-MM where xx=3, 6,10,15,25,30 and 50 foot cable).
- Use HD-ACT-xx-MM 4K HDMI Active Cables to connect an HDMI source or display up to 100 feet. (xx- 20,25,30,40,50,60,75 and 100 Feet)
- Use DP-HD-xx-MM cables to connect a DisplayPort source up to 15 feet away from the transmitter. (xx= 3,6,10 and 15 Feet)
- Use DVI-HD-xx-MM cable to connect a DVI source up to 5 meters. (xx- 1,2,3 and 5 meters)

Optional

PWR-SPLY-IPHDPOELCV4 110-240VAC, 50 or 60Hz-5VDC/3A AC Adapter with Line cord, country-specific

Cables and power supply can be purchased from Network Technologies Inc by calling (800) 742-8324 (800-RGB-TECH) in the US and Canada or (330) 562-7070 (worldwide).

CONNECTORS AND LEDS



#	LABEL	CONNECTOR/LED	DESCRIPTION
1	PWR	Blue LED	Illuminates to indicate proper power to the unit and normal operation
2	5V DC	2.1x5.5mm Power Jack	for connection of power supply
3	Arrows	Yellow LED	Indicates data transmission- flashes with network connectivity
4	Display	Green LED	Indicates connection to the network
5	LAN TX/RX	RJ45 Female connector	For connection of CATx cable between the Local and Remote Unit or between the Local/Remote unit and a router.
6	HDMI INPUT	HDMI Female	For connecting the video source
7	IR OUT	3.5mm Jack	For connecting the IR Emitter
8	RESET	Button	Press to refresh connection
9	HDMI OUTPUT	HDMI Female	For connecting the extended display
10	ir in	3.5mm Jack	For connecting the IR Receiver

INSTALLATION

Point to Point Connection

The Local and Remote Units can be connected directly to each other with CAT5e cable up to 328 feet (100 meters) long or with CAT6/6a/7 cable up to 394 feet (120 meters long). When connected in this manner (without a POE-enabled switch between them), a PWR-SPLY-IPHDPOELCV4 will be required at each end to provide power (sold separately).

If the IR feature will be used, connect the IR Receiver to the Remote Unit, and the IR Emitter to the Local Unit

Connect the video source and display to the Local and Remote Units using HD-xx-MM cables for best performance.



Figure 1-Point to point connection- directly

When connected through a POE-Enabled switch, the collective CATx cable can be twice as long and no power supplies will be needed.





Note: Only use a PWR-SPLY-IPHDPOELCV4 when the extender is <u>NOT</u> connected to a POE-enabled switch.

Daisy-Chained Switches

For even greater extended distances, daisy-chain multiple POE-enabled switches. Each can have up to 328 feet (100 meters) of CAT5e cable between them or up to 394 feet (120 meters long) of CAT6/6a/7 cable.



Figure 3-Daisy-Chained Switches

Point to Many Connection

Up to 253 Remote Units can be paired to a Local Unit.



Figure 4-Point to many connection

Many to Many Connection

When more than one Local Unit needs to be able to installed in a network to communicate with multiple Remote Units, a Managed Network Switch with POE support will be required. The managed switch must support port-based IEEE 802.1Q VLAN. Each VLAN acts as a separate HDMI Over IP Channel on the network and each VLAN channel supports one transmitter.



Figure 5-Many to many connection

Many-to-Many Configuration of ST-IPHD-POELC-V4 Extenders

A Many-to-Many configuration of the ST-IPHD-POELC-V4 extender allows multiple senders and multiple receivers to be connected to a single managed network switch wherein the switch can provide the routing of signals from senders to receivers. Through the assignment of VLAN groups, a sender can send video to multiple receivers within the same-named group.

Note: Only one sender can be connected per group.

Be sure to take note of which ports belong to each group assigned. Once the group is created, simply plug the sender and the receivers for the displays that are intended to receive video from the video source connected to the sender. The following procedures provide examples of just such a configuration.

Procedure to create a VLAN group for Cisco SG350 Series.

- 1. Connect an Ethernet cable between the PC and OOB port on the Cisco switch. The OOB port is the rightmost port on the front panel of the Cisco switch with an "OOB" label. (If your managed Cisco switch does not have an OOB port, just connect the PC to any Ethernet port on the switch.)
- 2. Change the PC's IP to be in the 192.168.1.x subnet.
- 3. Log into the web interface of the Cisco switch by visiting http://192.168.1.254 (the default IP of the switch).
- 4. Select "VLAN Management" on the leftmost list of the webpage.
- 5. In "VLAN Settings", click "Add.." to create a new VLAN group. (You could repeat this step to create multiple VLAN Groups.)
 - a. In the pop-up window, type a number between 2 and 4094 as the "VLAN ID" of the group. You could use any name you want for the "VLAN Name".
 - b. Click "Apply" to finish adding a new VLAN group.
- 6. Under "VLAN Management", click "Interface Settings".
 - a. If you see that the "Interface VLAN Mode" of the ports that you want to set up for your video extender are already set to "Access", you could skip this step and go to step 7.

If you see that they are set to "Trunk", continue to step 6(b).

- b. Choose a port you want to use, then click "Edit" on the bottom of the table.
- c. In the pop-up window, change the "Interface VLAN Mode" from "Trunk" to "Access". Click "Apply".
- d. Repeat step 6(b) and 6(c) to finish setting up all ports that you want to use.
- 7. Under "VLAN Management", click "Port VLAN Membership"
 - a. Select a port you want to use, then click "Join VLAN.." at the bottom of the table.
 - b. In the pop-up window, assign the "Access VLAN ID" of the desired VLAN group ID number for this port to be part of. Click "Apply".
 - c. Repeat step 7(a)-(b) to set up all ports that will be part of that group.
- 8. Repeat steps 5-7 for all VLAN groups that you want to create.

Now your VLAN groups should be configured correctly and ready for use.

Procedure to configure VLAN groups for a Netgear Managed Network Switch.

1. Connect an Ethernet cable between the PC and any Ethernet port on the Netgear switch. If your Netgear switch has a management port, use the management port instead.

- 2. Change the PC's IP to be in the 192.168.0.x subnet.
- 3. Log in to the web interface of the Netgear switch. (The switch we used has a default IP of http://192.168.0.239.)
- 4. Click the "Switching" Tab, and then go to "VLAN", "Advanced", and "VLAN Configuration".

System Switching Routing QoS Security Monitoring Maintenance Help Index												
System Switching	to VolD STD	Q05	Security	Monitoring	Maintenance	нер	Index					
		Multicast Addre		oop i rotection		Add	Doloto Concol Ann					
VLAN	VLAN Configura	ion				Add						
Basic 🗸		VLAN Name	VLAN Type									
Advanced ^	2	Group 2										
VLAN Configuration	1	default	Default									
• VLAN Membership	4088	Auto-VoIP	Auto-VoIP									
 VLAN Status 	4005	Auto-video	Auto-video									
Port PVID Configuration												
 MAC Based VLAN 	Reset											
 Protocol Based VLAN Group Configuration 	Reset Configur	ation										
 Protocol Based VLAN Group Membership 												
 Voice VLAN Configuration 												
 GARP Switch Configuration 												
 GARP Port Configuration 												

5. Under "VLAN Configuration", enter a VLAN ID (an integer between 2 and 4087) and a VLAN Name (whatever is preferable) in the textboxes as shown in the picture above. Click "Add" and then "Apply". You should see the page like shown in the picture on the next page. A new VLAN group is added.

NETGEAR										
GS110TPv3 8-Port Gigab	it Smart M	lanaged	Pro Switch	with PoE+ ar	nd 2 SFP Ports			Auto 🗸 V	Velcome admin 🕣	
System Switching	g Ro	outing	QoS	Security	Monitoring	Maintenance	Help	Index		
Ports LAG VLAN A	uto-VoIP	STP M	ulticast Ad	dress Table	L2 Loop Protection					
							Å	dd Delete	Cancel Apply	
VLAN		?								
•Basic v			VI AN Namo	VI AN T	100					
• Advanced			VLAN Name	VLAIN T	уре					
VI AN Configuration			default	Default						
	2		Group 2	Static						
VLAN Wembership	408	88	Auto-VoIP	Auto-Vo	IP					
VLAN Status	408	89	Auto-Video	Auto-Vio	deo					
 Port PVID Configuration 										
 MAC Based VLAN 	Posot									
 Protocol Based VLAN Group Configuration 										
 Protocol Based VLAN Group Membership 										
Voice VLAN Configuration										
 GARP Switch Configuration 										
GARP Port Configuration										
© 2020 NETGEAR, Inc. All rights	reserved.									

6. Under "Advanced" in the left menu, click "VLAN Membership". Under "VLAN Membership", choose the VLAN ID created in step 5. Under "Unit 1", click the ports that are in the selected VLAN group twice. Make sure the marking on the port is "U" (untagged), not "T" (trunk).Click "Apply". You should see a page similar to the picture shown below.

NETG	EAR [.]														
GS110TPv3	8-Port Gig	abit	Smart M	Manageo	d Pro Swit	ch with PoE+	and	2 SFP Ports					Auto ~	Welcom	e admin 🚽
System	Switc	hing	F	Routing	QoS	Securit	у	Monitoring		Maintenance	ŀ	lelp	Index		
Ports LA	G VLAN	Aut	o-VoIP	STP I	Multicast	Address Table	L2	Loop Protecti	on						
	/1 AN1		VLAN M	lembershi	ip									Canc	el Apply
V	LAN				P	-	-								0
• Dasic		~	VLAN I	ID O		2	<u></u>								
- Advanced	- finunation	^	Group	Operation	1	Unlag	All	~							
• VLAN CO	miguration		VLAN	Name			2								
- VLAN Me	andersnip		VLAN	туре											
Port PVIC) Configuratio	0.0	Uni	Unit 1											^
• MAC Bas	ed VI AN		Ports	1 3	5 7 9	7									
Protocol E	Based VLAN			═╠═╬											
Group Co	onfiguration			2 4	6 8 10										
Protocol E Group Me	Based VLAN embership		LAG									^			
Voice VLA Configura	AN ation														
 GARP Sw Configuration 	vitch ation		Ī												
• GARP Po Configura	ort ation														

9

7. Under "Advanced", click "Port PVID Configuration". Check the ports designated in step 6. In the textboxes at the top of the table, enter the VLAN group ID to the "PVID" and the "VLAN member" fields. Click "Apply".

System Switching Routing Routing Routing Routing Maintenance Heip Index Ports LAG VLAN Auto-VoIP STP Multicast Address Table L2 Loop Protection Advance Advanced I I IAG All Go To Interface Go Go VLAN PVID Configuration I Interface PVID CAN member VLAN Tag Acceptable Frame Ingress Filtering Current · VLAN Configuration I Interface PVID CAN member VLAN Tag Acceptable Frame Ingress Filtering Current · VLAN Membership · VLAN Status g1 1 None Admit All Disable Disable Disable · Port PVID Configuration g4 1 None Admit All Disable Disabl			Douting OoS Society Monitoring Maintenance Hole											
Ports LAG VLAN Auto-VolP STP Multicast Address Table L2 Loop Protection VLAN PVID Configuration I LAG All Go To Interface Go Advanced - - I LAG All Go To Interface Go • VLAN Configuration - - I LAG All Interface PVID PVID </th <th>System Switchin</th> <th>ng</th> <th>Routing</th> <th>QoS</th> <th>Security</th> <th>Monitoring</th> <th>Maintenance He</th> <th>elp Index</th> <th></th>	System Switchin	ng	Routing	QoS	Security	Monitoring	Maintenance He	elp Index						
VLAN PVID Configuration 3asic 1 LAG AII Go To Interface Go Advanced Interface PVID CAN member VLAN Tag Acceptable Frame Ingress Filtering Current • VLAN Configuration g1 1 None Admit AII Disable	orts LAG VLAN A	Auto-V	DIP STP	Multicast	Address Table L	2 Loop Protection								
VLAN PVID Configuration Basic 1 LAG AII Go To Interface Go Advanced Interface PVID CAN member VLAN Tag Acceptable Frame Ingress Filtering Current VLAN Configuration 91 1 None Admit AII Disable								Ca	ncel Apply					
Basic I LAG AII Go To Interface Go Advanced • Interface PVID CAN member VLAN Tag Acceptable Frame Ingress Filtering Current • VLAN Configuration • 2 2 •	VLAN	PV	ID Configura	tion					C					
Advanced Interface PVID CAN member VLAN Tag Acceptable Frame Ingress Filtering Current · VLAN Configuration · VLAN Membership · ULAN Status • g1 1 1 None Admit All Disable Disab	asic	. 1					Ga	To Interface	Go					
Advanced Interface PVID CAN member VLAN Tag Acceptable Frame Ingress Filtering Current · VLAN Configuration · VLAN Membership 2 2 2 · · · · · · · · · · · · · · · · · · ·					1		00		00					
• VLAN Configuration 2 1 1 None Admit All Disable Disable 2 2 2 1 1 None Admit All Disable Disable 2 2 1 1 None Admit All Disable Disable Disable 2 2 1 1 None Admit All Disable Disable 2 2 1 1 None Admit All Disable Disable 2 2 1 1 1 1 1 1 1 2 1 1 2 1 1 1 1 1 1 1 1 1 1 <td>dvanced</td> <td>^ C</td> <td>Interface</td> <td>PVID V</td> <td>LAN member</td> <td>VLAN Tag</td> <td>Acceptable Fr</td> <td>ame Ingress Filtering</td> <td>g Current</td>	dvanced	^ C	Interface	PVID V	LAN member	VLAN Tag	Acceptable Fr	ame Ingress Filtering	g Current					
• VLAN Membership g1 1 1 None Admit All Disable Disable • VLAN Status g2 1 1 None Admit All Disable Disable • Port PVID Configuration g3 1 1 None Admit All Disable Disable • MAC Based VLAN g4 1 1 None Admit All Disable Disable • Protocol Based VLAN g5 1 -2 None Admit All Disable Disable Disable • Protocol Based VLAN g6 1 -2 None Admit All Disable Disable Disable • Protocol Based VLAN g9 1 1-2 None Admit All Disable Disable Disable • Protocol Based VLAN g9 1 1-2 None Admit All Disable Disable Disable • Protocol Based VLAN g9 1 1 None Admit All Disable Disable Disable • Origination g9 1 None Admit All Disable	VLAN Configuration			2 2	K			¥ ¥						
·VLAN Status g2 1 1 None Admit All Disable Disable ·Port PVID Configuration g3 1 1 None Admit All Disable Disable ·MAC Based VLAN g5 1 12 None Admit All Disable Disable ·Protocol Based VLAN g6 1 1-2 None Admit All Disable Disable ·Protocol Based VLAN g7 1 1-2 None Admit All Disable Disable ·Protocol Based VLAN g9 1 1-2 None Admit All Disable Disable ·Protocol Based VLAN g9 1 1-2 None Admit All Disable Disable ·Protocol Based VLAN g9 1 None Admit All Disable Disable Disable ·Protocol Based VLAN g8 1 None Admit All Disable Disable ·Protocol Based VLAN g9 1 None Admit All Disable Disable ·Voice VLAN g9 1 N	VLAN Membership	C	g1	1 1		None	Admit All	Disable	Disable					
• Port PVID Configuration 93 1 1 None Admit All Disable Disable • Port PVID Configuration 94 1 1 None Admit All Disable Disable • MAC Based VLAN 95 1 1-2 None Admit All Disable Disable • Protocol Based VLAN Group Configuration 2 96 1 1-2 None Admit All Disable Disable <t< td=""><td>VI AN Status</td><td>C</td><td>g2</td><td>1 1</td><td></td><td>None</td><td>Admit All</td><td>Disable</td><td>Disable</td></t<>	VI AN Status	C	g2	1 1		None	Admit All	Disable	Disable					
• Point PVID Configuration g4 1 1 None Admit All Disable Disable • MAC Based VLAN g5 1 1-2 None Admit All Disable Disable Disable • Protocol Based VLAN Group Configuration g6 1 1-2 None Admit All Disable Disable <td></td> <td>0</td> <td>g3</td> <td>1 1</td> <td></td> <td>None</td> <td>Admit All</td> <td>Disable</td> <td>Disable</td>		0	g3	1 1		None	Admit All	Disable	Disable					
• MAC Based VLAN Image: gg	Port PVID Configuration	0	g4	1 1		None	Admit All	Disable	Disable					
• Protocol Based VLAN Group Configuration	MAC Based VLAN		g 5	1 1	-2	None	Admit All	Disable	Disable					
Group Configuration Image: gr marked state s	Protocol Based VLAN		2 g6	1 1	-2	None	Admit All	Disable	Disable					
Protocol Based VLAN Group Membership g9 1 1 None Admit All Disable D	Group Configuration	5	2 g7	1 1	-2	None	Admit All	Disable	Disable					
Group Membership g9 1 None Admit All Disable Disable • Voice VLAN Configuration g10 1 1 None Admit All Disable Disable • GARP Switch Configuration 1 LAG All Go To Interface Go	Protocol Based VLAN		g8	1 1		None	Admit All	Disable	Disable					
Voice VLAN Configuration GARP Switch Cardinuction I LAG All Go Configuration Go Configuration	Group Membership	C	g9	1 1		None	Admit All	Disable	Disable					
Configuration -GARP Switch 1 LAG All Go To Interface Go	Voice VLAN	C	g10	1 1		None	Admit All	Disable	Disable					
GARP Switch 1 LAG All Go To Interface Go	Configuration													
	GARP Switch	1	LAG All				Go	To Interface	Go					
Connguration	Configuration													
• GARP Port	GARP Port													

© 2020 NETGEAR, Inc. All rights reserved. 8. Now you should see a page as shown in the picture below, with PVID and VLAN member fields updated for g5, g6 and g7.

				ICH WITH FOL . al	IG Z SEP POILS		Auto	 veicon 	ie aumin
System Switching		Routing	Qo	S Security	Monitoring	Maintenance	Help I	ndex	
ts LAG VLAN Auto	-Voll	P STP	Multicast	Address Table	L2 Loop Protection				
								Can	cel Ar
VLAN	PVID	Configurat	tion					Oun	ion inp
sic	11					G	o To Interface		Go
		10 741				0	o to interface	·	
vanced ^		Interface	PVID	VLAN member	VLAN Tag	Acceptable	Frame	Ingress Filtering	Current
/LAN Configuration							~	~	
/LAN Membership		g1	1	1	None	Admit All		Disable	Disable
/I AN Status		g2	1	1	None	Admit All		Disable	Disable
		g3	1	1	None	Admit All		Disable	Disable
Port PVID Configuration		g4	1	1	None	Admit All		Disable	Disable
AC Based VLAN		g5	2	2	None	Admit All		Disable	Disable
Protocol Based VLAN		g 6	2	2	None	Admit All		Disable	Disable
Group Configuration		g7	2	2	None	Admit All		Disable	Disable
Protocol Based VLAN		g8	1	1	None	Admit All		Disable	Disable
Group Membership		g9	1	1	None	Admit All		Disable	Disable
/oice VLAN		g10	1	1	None	Admit All		Disable	Disable
oniguration									
GARP Switch	1 L	ag ali				G	to To Interface	1	Go
Configuration									

© 2020 NETGEAR, Inc. All rights reserved.

9. Repeat steps 5-8 for other VLAN groups that you want to create. Now your VLAN groups should be configured correctly and ready for use.

TECHNICAL SPE	CIFICATIONS
Local Unit	
Ports	1- HDMI-A Female (Video source)
	1- RJ45 Female, 1000Mbps (CATx connection)
	1- 3.5mm Female (IR Emitter)
Encoding Delay	80 ms latency
Remote Unit	
Ports	1- HDMI-A Female (Display)
	1- RJ45 Female, 1000Mbps (CATx connection)
	1- 3.5mm Female (IR Receiver)
Audio Supported	Embedded Digital Audio through HDMI compatible TVs or audio receivers.
HDCP Supported	V1.4
General	
Operating Temperature	32 to 140°F (0 to 60°C)
Storage Temperature	-4 to 158°F (-20 to 70°C)
Operating and storage relative humidity	0 to 95% non-condensing RH
Resolutions Supported	480i@60Hz, 480p@60Hz, 576i@50Hz, 576p@50Hz, 720p@50/60Hz, 1080i@50/60Hz, 1080p@50/60Hz
IR Frequency Range	20 to 60 kHz
HDCP Supported	V1.4
HDMI Supported	V1.4
CATx cable supported	CATx solid or stranded straight through cable for TIA/EIA-568B wiring terminated with standard RJ45 connectors.
	394 feet (120 meters) over CAT6/6a/7 cable
	328 feet (100 meters) over CAT5e cable.
Cascading supported	Up to 3 switches- max cable length between the first switch/transmitter and the last switch/receiver is 1,575 feet (480 meters) for CAT6/6a/7 or 1,312 feet (400 meters) for CAT5e cables
Multiple Transmitter supported	Requires managed network switch with VLAN support. Managed switch must support port-based IEEE 802.1Q VLAN.
	Local and Remote Units must be on same LAN. WAN not supported.
Ethernet connection	1000 Base-T
EDID	Built-in Table
Power Supply	Power over Ethernet: With a switch that supports Power over Ethernet (Local: 4.5W, Remote: 3.5W)
	OR
	PWR-SPLY-IPHDPOELCV4: Output: 5VDC, 3.0A
Size (WxDxH)	4.44x3.71x0.94 In. (113x94x24 mm)
Approvals	CE, FCC, RoHS

TROUBLESHOOTING

Problem: Display indicates "Waiting for connection"

Solution: Verify the extender Local and Remote are both connected to either POE enabled switch or to a connected power supply, and if power supplies, check that the DC plugs are fully inserted.

Problem: Display indicates" Please check the TX input signal"

Solution: Verify that the video source cable is well connected at each end and that the video source is powered ON. **Solution**: Try connecting the video source directly to the display and verify there is a signal from the source and that the source and display settings are correct.

Problem: Display not stable

Solution: Make sure the cables are properly connected and that the CATx cable is the correct type and within the specified range. **Solution:** Press the "reset" button on the Local and/or Remote Unit front panels. Allow units to reset and reconnect.

WARRANTY INFORMATION

The warranty period on this product (parts and labor) is two (2) years from the date of purchase. Please contact Network Technologies Inc at **(800) 742-8324** (800-RGB-TECH) or **(330) 562-7070** or visit our website at http://www.networktechinc.com for information regarding repairs and/or returns. A return authorization number is required for all repairs/returns.

MAN411 Rev. 9/24/21