
Operating Instructions

Thanks for purchasing our product Please be sure to read this instruction manual carefully before using our product.



Model: HKET0250NC20



Contents Product Overview1 Feature1 Package Contents Specifications Panel Descriptions ------3 EQ and EDID imformation Troubleshooting and Maintenance7 Warning and Precautions 7

Product Overview

HDMI Extender HKET0250NC20 is the HDMI 2.0 version, with 1 HDMI Input, 1 HDMI Output by HDMI cable and 1 HDMI output by cat extended , support 2160P@60Hz , HDCP2.2, 3D, easy for operation and widely applied in home, theatre, shopping mall, school, conference, hotel installation industry.


1

Features

- Support 4K/60Hz and below video output formats.
- Support HDMI2.0, HDCP 2.2 and 3D.
- 1 HDMI Input, 1HDMI Loop Output, 1 HDMI output by cat extended.
- Support 5V power supply. • Easy installation and operation.

Package Contents


① 1xHKET0250NC20-TX ② 1xHKET0250NC20-RX ③ Operating instructions ④ 2xDC5V Power Adapter ⑤ 2xAC plug 6 IR TX cable ⑦ IR RX cable



Specifications

-5 to +45°C (+23 to +113 °F)
5 to 90 % RH (no condensation)
0.5-1.0 volts p-p
5 volts p-p (TTL)
4K60Hz/4K30Hz/1080p/1080i/720p/576p/480p /576i/480i
HDMI 2.0
Support DTS-HD
4K≤8m,1080P≤15m
Cat6A≤45m,Cat6≤40m
DC 5V
2x4Watts
70mmL×80mmW×22mmH
0.25Kg

2



EQ and EDID imformation

DIP Switch1	DIP Switch2	DIP Switch3	EQ Boost at 850Mhz(dB)
0	0	0	9
0	0	1	14
0	1	0	18
0	1	1	21
1	0	0	24
1	0	1	26
1	1	0	28
1	1	1	30

		DIP Switch3	EDID Information
0	0	0	4K@60Hz, HDR
0	1	0	EDID copy from TX
1	0	х	EDID copy from RX
1	1	х	1080p@60Hz 2.1ch

Troubleshooting and Maintenance

- 1) If colour distorted or no video signal output:
- a) check the corresponding input signal, if there is no input signal, please check the wire connection.
- b) check the output interface is consistent with the right controlled one. 2) If the front panel digital light is with no shine and operating unresponsive, please ensure the power input is in well-connected.
- 3) Clean this unit with a soft, dry cloth. Never use alcohol, paint thinner or

Warning and Precautions

- 1) Away from the heat source and avoid direct sunlight.
- 2) To ensure proper heat dissipation, avoid poorly ventilated spaces and do not block the vents.
- 3) To prevent electrical shock and fire, do not keep the machine in rain or
- wet places.4) Do not connected to power supplies when installation or moving the device.
- 5) Do not touch the power adapter plug with wet hands.
- 6) Do not spill liquid on the machine, as it may cause internal short circuit or fire
- 7) Do not attempt to open the cabinet. Please contact qualified service personnel for maintenance.