

# F-2A-B-XLR-TX/RX

## Quick Setup Guide

This guide also applies to model F-2A-B-XLR-TX/RX-RM (Rack Mounted)

### Step 1: Connect Power

- Connect the included power supplies to the TX (Transmitter) and RX (Receiver)
- PWR LED indicators on both units will light constant GREEN



Connect Power



"PWR" LED

### Step 2: Connect Fiber

Connect Transmitter to Receiver using Single Mode Fiber (Not Included)

Distance up to 20km



"FIBER" LEDs on both T and R indicate fiber is properly connected

### Step 3: Audio Connection (Example)



Tx Audio IN1 = Rx Audio OUT1  
 Tx Audio IN2 = Rx Audio OUT2  
 Tx Audio OUT1 = Rx Audio IN1  
 Tx Audio OUT2 = Rx Audio IN2

