

WolfPack 4K60 Modular Matrix Switcher

—With TV Wall Function



Chassis Selection: WolfPack Chassis Series

Modular Chassis

Buttons with Lights

2-key fast switch


WEB GUI Control

Dual RS232


- 9x9, 18x18 and 36x36 chassis
- 10ms Seamless switching
- 4K60Hz, HDCP2.2, HDMI2.0, DolbyVision
- DIP Switch for resolution adjustment
- 1 card 1-port
- Android and iOS App Control



9x9 Card Cage



18x18 Card Cage



36x36 Card Cage

Input and output card

4K60 HDMI2.0 Input Card





- 1 card 1 HDMI input
- 18G 4K/60 4:4:4 at 18 GBPS
- HDCP2.2, HDR
- 3.5 mm audio embedded
- 10ms Seamless switching

4K60 HDMI2.0 Output Card



- 1 card 1 HDMI output
- 18G 4K/60 4:4:4 at 18 GBPS
- HDCP2.2, HDR
- 3.5 mm audio de-embedded
- 10ms Seamless switching


WEB Control



x: y:



WEB Control Operation Steps




Step 1: Type the IP address here

A login form titled "Please login" is shown. It contains two input fields: the first is labeled "admin" and the second is filled with six dots. Below these fields is a blue button labeled "Login". The entire form is enclosed in a red rectangular box, with a red arrow pointing from the text "Step 2: Enter the user name and password, Click to Login" to the bottom of the box.

Step 2: Enter the user name and password,
Click to Login

WEB Control Operation Steps



TV Wall set up

x: y:




Delete the TV Wall



Set up a 3x4 TV Wall

Function shortcut buttons

WEB Control Operation Steps






x: 3 y: 4 add del



Step 4: Drag the outputs down to the TV Wall



WEB Control Operation Steps



Step 5: Drag the corresponded outputs to the TV Wall until it's all full filled

3x4 TV Wall

WEB Control Operation Steps



WEB Control Operation Steps

