HDMI Matrix Over LAN with PC or App Control

Important Safety Instructions

- 1. Please read the user manual carefully before use this product and keep these instructions.
- 2. Do not mix up transmitters and receivers before installation.
- Channel of the transmitter (TX) must be different, otherwise, the system would be breakdown(including transmitter, receiver, IGMP switch etc.).
- 4. It is advised to set channel of transmitter before access to switch.
- 5. Follow all instructions.
- 6. This extender must be installed and operated within the limits of specified operating temperature and humidity.
- 7. Do not place objects on top of the unit.
- 8. Do not position the matrix extender near any heating source such as heater, radiator, or direct exposure to sun.
- 9. Prevent entering of water and moisture into the unit. If necessary, use dehumidifier to reduce humidity.
- 10. This product must be used with the IGMP switch.
- 11. Use DC5V/2A power supply only. Make sure the specification matched if using 3rd party DC adapters.

Product Introduction

This HDMI video matrix over IP includes a transmitter unit (TX) and a receiver unit (RX). It allows for the distribution and switching of high-definition video/audio signal by this product and off-the-shelf IGMP switch. It applied advanced technology; the resolution supported is up to

4Kx2K@30Hz ultra-HD. It can also be used in a point-to-point connection, the distance is up to 120 meters. It is widely applied in digital signage advertisement, control room, command centers, entertainment and exhibition center, safety monitoring system, etc.

Product Features

- 1. Apply advanced over IP technology.
- 2. Resolution supported is up to 4K×2K@30Hz ultra-HD.
- 3. Transmission distance is up to 120 meters via CAT6.
- 4. Support IR pass back function to control source device from RX location.
- 5. Plug and play.
- 6. Support scalable and flexible input-output matrix configuration, allows 100 inputs to infinite output.
- 7. Support computer control software to select and switch source device input.
- 8. Support to select and switch source device input from receiver via remote control and hard button.

9 Surge Protection, Lightning Protection, ED Protection.

Package Content



Transmitter unit ×1pc



IR OUT IR blaster extension cable x1pc



Receiver unit ×1pc



IR receiver extension cable ×1pc





User manual ×1pc

Power supply

(DC5V) ×2pcs

Remote control ×1pc

Wall-mount kit ×4pcs

Screws ×8pcs

Installation Requirements

HDMI source devices: with HDMI OUTPUT interface, DVD, PS3,

Panel Description

Transmitter unit



- 1. IR receiver window: remote control channel
- 2. 2. Power indicator
- 3. 3 TX ID: Mark transmitter unit's channel as a number, indicator of the current TX ID number
- 4. 4 DC5V power input
- 5. Data transmission indicator
- 6. RJ45 signal output
- 7. Connection indicator
- 8. IR blaster extension cable interface
- 9. HDMI signal input
- 10. RESET button

Receiver unit



- 1. RX ID: Mark receiver unit as a number, indicator of the current RX ID number
- 2. IR receiver window: remote control channel
- 3. ® Power indicator
- 4. TX CONNECTED: Indicate the input channel as a number, and when the channel of receiver as same as the channel of transmitter, transmission connected
- 5. DC5V power input

- 6. Data transmission indicator
- 7. RJ45 signal input
- 8. Connection indicator
- 9. I receiver extension cable interface
- 10. HDMI signal output
- 11. ® RESET button

Installation and Connection

How to make a CAT5/5E/6 network cable Follow the standard of IEEE-568B:

Connection Drawing 2.1 Matrix configuration



[NOTE] : The switch must support IGMP function

- 1. IR use guide
 - IR passback
 - IR blaster extension cable should plug into the IR-out port of TX

- (Transmitter) of this extender matrix, and the IR receiver extension cable should plug into the IR-in port of the RX (Receiver) of this matrix extender. The emitter of IR blaster should as close as possible to the IR receiver window of the signal source device.
 3.2 IR remote control Using the IR remote controller to set/select the channel of this HDMI video Matrix
- 1. Button control

There is a "TX ID" on TX unit, and there are both "RX ID" and "TX connected" on the RX unit.



Each of them consists of two Nixie tubes and two buttons (beside the Nixie tube), the left button controls the value of the left Nixie tube, and the right one to control the value of the right Nixie tube. The value of each Nixie tube is from 0 to 9, each button is pressed at a time, the number is added one value. For example, the existing value of TX ID is "00", and press the left button once, also press the right button once, then the value of TX ID is changed to" 11" When the value of "TX connected" on the RX unit is as same as the value of "TXID" on the TX unit, a connection built between the TX and RX units.

Short press: Press to set IGMP group and display the set value.

Product switches automatically to the corresponding IGMP group 5 seconds after the press.

Long press: Press and keep 3 seconds to reset the product.

Computer software control use guide

 Access to network
 Connect your PC/computer with the off-the-shelf IGMP
 Ethernet switch via a single network cable
 2 PC/computer setting
 Change the PC/computer's IP to <u>192.168.1.xXx</u>
 (XXX can be 0 to 255), which as same as the IP segment of TX
 unit and RX unit.
 Web operation
 Open application program "HDbitTE-Matrix Control center", it
 displays the interface as Figure 1(Download from the website: https://hdtvsupply.ladesk.com/031028-4K-Matrix-PC-Software

uniza: 0	\rightarrow	Device scan page connected device of those devices	allow you s and set co	to scan tl onfigurat
Nane	TX ID	RX ID	Nane	TX Connected
TX_1	90	94	RX-TV41	60
TX_2	86	10	BX_TV32	90
ТХ_З	60	15	RX_TV37	77
TX_4	77	23	RX_TV60	60
TX/R	X's IP			Mode

IP setting

TX and RX have their own default IP address, TX's IP is 192.168.1.238, and RX's IP is 192.168.1.239. Generally, it is no need to change the device IP address, as the system can work normally even though multiple TX units and multiple RX units connected into the system with their default IP address.

If IP setting is really needed, please follow up the operation as Figure 2 (here make an example of TX's IP setting only, RX's setting is the same as TX's

	Device Selection			
C Device: 4	(ID Coho		-	TV Connected
TX_1	IP: 192 . 168	. 1 . 238	32	90
TX_ 2 TX_ 3	Netmask: 255 . 255	. 255 . 0 Set byc	IP , and licking Jpdate"	d save button
TX_ 4	Gateway: 192 . 168	. 1 . 254	50	77
ick button_"TX_se	tup",	hose DHCP		

Figure 2

Device scanning and setting

(here make an example of TX's setting only, RX's setting is same as TX's)

* Click button "Start Scan", the scanned result shows as Figure 3

y Device: 4		Ry Device' 4		V	
Name	TX ID	RX ID	Name	TX Cor	nnected
TX_1	86	10	RX_TV32	90	
TX_2	60	15	RX_TV37	86	
тх_з	90	94	RX-TV41	60	Scan resul
TX_4	77	23	RX_TV60	77	
_				_	

Figure 3

Device Name setting as Figure 4

x Device: 4	Change Name		
Name		Nane	TX Connected
TX_1	TX 1	RX_TV32	90
TX_ 2		RX_TV37	86
TX_ 3	OK Cande	RX-TV41	60
TX_ 4		RX_TV60	77

Figure 4

Device channel (TX ID) setting as Figure 5

Device Scan Time: 3	Seconds			Start Scan
Device: 4		-Ra Device: 4-		
Name	TX ID	RX ID	Nane	TX Connected
TX_1	87 👻	10	RX_TV32	90
TX2	83 84 85	15	RX_TV37	86
π	86 87 88	94	RX-TV41	60
_xT	91 92	23	RX_TV60	77
4	93 94 95			
	96 97 98 99			

Click button "Update" new configuration saved Pre-operation mode editing , show as Figure 6

0.000			T 6567775		Save Mode
Bune	TX ID	RX ID	Nane	TX Connec	
TX_1	90	94	EX-TV41	86	
TX_2	86	10	RX_TV32	90	NEW_MODE01
ТХ_3	60	15	EX_TV37	77	
TX_4	77	23	EX_TV60	60	OK Cand
	for the inp	ut / output		pro Bu	e-mode, press "OK" tton to save

Figure 6

Operation mode selection setting

Follow up Figure 7, Click button "Select Mode" to choose the mode needed.

vice: 0		-Rx Device: 0-		
Nane	TX ID	EX ID	Nane	TX Connected
TX_1	90	94	RX-TV41	60
TI_2	86	10	RX_TV32	90
ТХ_3	60	15	RX_TV37	77
TI_4	77	23	RX_TV60	60

Figure 7

FAQ

Q: TV display "Waiting for connection" on the right corner?

A: 1) Please check if the cable is correct and the length is within the range this unit supported.

2) Please check and make sure receiver's channel number is within transmitter's channel list.

3) Please check and make sure all the transmitter's channel are different.

Q: TV display "Please check the transmitter input signal"?

A: 1) please check if there is a HDMI signal input of transmitter.

2) Try to connect the signal source directly to display device to see if

there is signal output from source device, or change the signal source, HDMI wire and try again.

Q: Display is not fluent, not stable?

A: 1) Please check and make sure the switch is with IGMP function, and the IGMP function is open.

Q: Black screen or no image on displays?

A: 1) Cut off the input of source device, if TV displays "Please check the transmitter input signal" after about 10 seconds, please connect the source again, change and try another resolution.

Specifications:

Item	Specification
HDMI signal	HDMI1.4,compliant to HDCP
Network bandwidth	18Mbps
HDMI input resolution supported	480i@60Hz, 480p@60Hz, 576i@50Hz, 576p@50Hz, 720p@50/60Hz, 1080i@50/60Hz, 1080p@50/60Hz, 4Kx2K @24/25/30Hz
Audio format supported	PCM
TMDS signal	0.7~1.2Vp-p
DDC signal	5Vp-p
Remote control	Support
IR passback	Supports 20~60KHz IR devices
Matrix configuration	Up to 100 source signals can be connected and switched to infinite output
Voltage/Current	5V/2A
Power consumption	TX≤6W;RX≤5W
Weight	TX: 320g ; RX: 310g
Dimensions(LxWxH)	164×107.6×23.6mm
Working temperature	0~60°C
Storage temperature	-20~70°C
Humidity	0~95%(no condensation)
Color	Black
Protection	Lightning Protection/Surge Protection/ ESD protection