


# ANI-16-4K60-S

16x16 UHD 4K@60Hz HDR HDMI MATRIX SWITCHER w/ Scaler



## PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- ANI-16-4K60-S 16x16 UHD 4K@60Hz HDR HDMI Matrix Switcher w/ Scaler
- 24V/3.75A Power Adapter
- IR Remote
- RS-232 serial cable (1.5M, male to female head)
- (2) Mounting Ear



## SAFETY INFORMATION



1. To ensure the best results from this product, please read this manual and all other documentation before operating your equipment. Retain all documentation for future reference.
2. Follow all instructions printed on unit chassis for proper operation.
3. To reduce the risk of fire, do not spill water or other liquids into or on the unit, or operate the unit while standing in liquid.
4. Make sure power outlets conform to the power requirements listed on the back of the unit. Keep unit protected from rain, water and excessive moisture.
5. Do not attempt to clean the unit with chemical solvents or aerosol cleaners, as this may damage the unit. Dust with a clean dry cloth.
6. Do not use the unit if the electrical power cord is frayed or broken. The power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords and plugs, convenience receptacles, and the point where they exit from the appliance.
7. Do not force switched or external connections in any way. They should all connect easily, without needing to be forced.
8. Always operate the unit with the AC ground wire connected to the electrical system ground. Precautions should be taken so that the means of grounding of a piece of equipment is not defeated.
9. AC voltage must be correct and the same as that printed on the rear of the unit. Damage caused by connection to improper AC voltage is not covered by any warranty.
10. Turn power off and disconnect unit from AC current before making connections.
11. Never hold a power switch in the "ON" position.
12. This unit should be installed in a cool dry place, away from sources of excessive heat, vibration, dust, moisture and cold. Do not use the unit near stoves, heat registers, radiators, or other heat producing devices.
13. Do not block fan intake or exhaust ports. Do not operate equipment on a surface or in an environment which may impede the normal flow of air around the unit, such as a bed, rug, carpet, or completely enclosed rack. If the unit is used in an extremely dusty or smoky environment, the unit should be periodically "blown free" of foreign dust and matter.
14. To reduce the risk of electric shock, do not remove the cover. There are no user serviceable parts inside. Refer all servicing to qualified service personnel. There are no user serviceable parts inside.
15. When moving the unit, disconnect input ports first, then remove the power cable; finally, disconnect the interconnecting cables to other devices.
16. Do not drive the inputs with a signal level greater than that required to drive equipment to full output.
17. The equipment power cord should be unplugged from the outlet when left unused for a long period of time.
18. Save the carton and packing material even if the equipment has arrived in good condition. Should you ever need to ship the unit, use only the original factory packing.
19. Service Information Equipment should be serviced by qualified service personnel when:
  - A. The power supply cord or the plug has been damaged.
  - B. Objects have fallen, or liquid has been spilled into the equipment.
  - C. The equipment has been exposed to rain.
  - D. The equipment does not appear to operate normally, or exhibits a marked change in performance.
  - E. The equipment has been dropped, or the enclosure damaged.

## ▶ CONTENTS

INTRODUCTION .....	1
<b>FEATURES &amp; SPECIFICATIONS</b> .....	2
<b>FRONT &amp; REAR PANELS</b> .....	3
<b>REMOTE CONTROL</b> .....	5
<b>RS-232 CONTROL COMMANDS / ASCII COMMANDS</b> .....	6
<b>EDID MANAGEMENT</b> .....	12
<b>WEB GUI USER GUIDE</b> .....	14
<b>APPLICATION EXAMPLE</b> .....	20

## DEAR CUSTOMER

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

## INTRODUCTION

The ANI-16-4K60-S 18Gbps 16x16 HDMI Matrix supports the transmission of video (resolution up to 4K2K@60Hz YUV 4:4:4) and multi-channel high resolution digital audio from (16) HDMI sources to (16) HDMI displays. Audio de-embedded to coaxial audio is supported from (16) HDMI output ports. While HDMI output ARC function is enabled, the ARC audio from HDMI display devices will be extracted to coaxial audio output. Each HDMI output of this 16x16 HDMI Matrix supports 4K2K to 1080P downscaler independently. Control via front panel buttons, IR remote, RS-232, LAN and Web GUI. This product has a 3 year warranty.

## SAFETY PRECAUTIONS

Please read all instructions before attempting to unpack, install or operate this equipment and before connecting the power supply. Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through any openings or empty slots in the unit, as you may damage parts inside the unit.
- Do not attach the power supply cabling to building surfaces.
- Use only the supplied power supply unit (PSU). Do not use the PSU if it is damaged.
- Do not allow anything to rest on the power cabling or allow any weight to be placed upon it or any person walk on it.
- To protect the unit from overheating, do not block any vents or openings in the unit housing that provide ventilation and allow for sufficient space for air to circulate around the unit.

## DISCLAIMERS

The information in this manual has been carefully checked and is believed to be accurate. We assume no responsibility for any infringements of patents or other rights of third parties which may result from its use.

We assume no responsibility for any inaccuracies that may be contained in this document. We make no commitment to update or to keep current the information contained in this document.

We reserve the right to make improvements to this document and/or product at any time and without notice.

## COPYRIGHT NOTICE

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means — electronic, mechanical, magnetic, optical, chemical, manual, or otherwise — without the express written permission and consent.

© Copyright 2022. All Rights Reserved.  
Version 1.6 JAN 2022

## TRADEMARK ACKNOWLEDGMENTS

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.

## FEATURES

- HDMI 2.0b, HDCP 2.2/1.x and DVI 1.0 compliant
- Video resolution up to 4K2K@60Hz (YUV 4:4:4) on all HDMI ports
- Support 18Gbps video bandwidth
- HDR, HDR10, HDR10+, Dolby Vision and HLG are supported
- Support 4K->1080P Down Scaler for each output port
- HDMI audio pass-through up to 7.1CH HD audio (LPCM, Dolby TrueHD and DTS-HD Master Audio)
- Audio de-embedded is supported via coax ports
- ARC, CEC and smart EDID management are supported
- 1U rack mounted design with front panel OLED display
- Control via front panel buttons, IR remote, RS-232, LAN and Web GUI

## SPECIFICATIONS


- **HDMI Compliance:** HDMI 2.0b
- **HDCP Compliance:** HDCP 2.2/1.x
- **Video Bandwidth:** 18Gbps
- **Video Resolution:** Up to 4K2K@60Hz (4:4:4)
- **Color Space:** RGB, YCbCr 4:4:4/4:2:2/4:2:0
- **Color Depth:** 8-bit, 10-bit, 12-bit
- **HDMI Audio Formats (Pass-through):** LPCM 2/5.1/7.1, Dolby Digital, DTS 5.1, Dolby Digital+, Dolby TrueHD, DTS-HD Master Audio, Dolby Atmos, DTS:X
- **Coax Audio Formats:** LPCM 2.0, Dolby Digital / Plus, DTS 5.1
- **HDR Formats:** HDR10, HDR10+, Dolby Vision, HLG
- **ESD Protection Human Body Model:**
  - ± 8kV (air-gap discharge)
  - ± 4kV (contact discharge)
- **Input Ports:** (16) HDMI Type A [19-pin female]
- **Output Ports:**
  - (16) HDMI Type A [19-pin female]
  - (16) Coax Audio (RCA)
- **Control Ports:**
  - TCP/IP [RJ45]
  - RS-232 [D-Sub 9]
- **Housing:** Metal Enclosure
- **Color:** Black
- **Dimensions (WxDxH):** 19 x 7.9 x 1.7 in (440x200x44mm)
- **Weight:** 6.8lb / 3.1Kg
- **Power Supply:** Input: AC 100 - 240V 50/60Hz, Output: DC 24V/3.75A (US/EU standard, CE/FCC/ULcertified)
- **Power Consumption:** 76.8W
- **Operating Temperature:** -10°C ~ 45°C / 14°F ~ 113°F
- **Storage Temperature:** -20°C ~ 60°C / -4°F ~ 140°F
- **Relative Humidity:** 20~90% RH (non-condensing)

As product improvements are continuous, specifications are subject to change without notice.

Resolution / Cable Length	4K60	4K30	1080P60
HDMI IN / OUT	16ft / 5M	32ft / 10M	50ft / 15M

The use of “Premium High Speed HDMI” cable is highly recommended.

### FRONT PANEL



**1 OLED SCREEN:** Display matrix switching status, input / output port, EDID, Baud rate, IP Address.

**2 POWER LED:** The LED will illuminate in green when the product is connected to power supply, and red when the product is on standby.

**3 INPUT / OUTPUT BUTTONS:** You need to press input button (1~16) firstly, then press the “AV” button, finally press input button (1~16, including “ALL”) to select the corresponding input and output ports.

**4 AV / ALL BUTTONS:**

**AV:** Used to switch signal source to output.

e.g. Pressing “1→AV→3” represents signal source 1 is output to display 3.

**ALL:** It represents all the output ports.

e.g. Pressing “1→AV→ALL” represents signal source 1 is output to all displays.

**5 MENU / ENTER / UP / DOWN:**

**1 Switching Status Check:** On the initial OLED display screen, press “MENU” button to enter the Matrix switching status interface, then press “UP/DOWN” button to check the switching state of all ports.


**2 EDID Setting:** On the initial OLED display screen, press “MENU” button to enter the EDID setting interface, press “UP/DOWN” button to select the required EDID, and press the “ENTER” button. A prompt “copy to input :” will appear. Then press “UP/DOWN” button to select the input port you need to set, and press “ENTER” button again to confirm.

**3 Baud Rate Setting:** On the initial OLED display screen, press “MENU” button to enter the Baud rate interface, and press “UP/DOWN” button to select the required Baud rate, finally press the “ENTER” button to confirm the setting.

**4 IP Address Check:** On the initial OLED display screen, press “MENU” button to enter the IP interface, then press “UP/DOWN” button to check the current IP address. Pressing the “MENU” button again will return to the initial OLED display status.


**6 IR WINDOW:** IR receiver window, it only receives the IR remote signal from this product.

## REAR PANEL



- ❶ **TCP/IP PORT:** TCP/IP control port, connect to PC or router with an RJ45 cable.
- ❷ **RS-232 PORT:** Connect to a PC or control system by D-Sub 9-pin cable to transmit RS-232 command.
- ❸ **AUDIO OUT (1-16):** Coaxial audio output port, connect to audio output device such as audio amplifier via a coaxial cable.
- ❹ **DC 24V:** Connect to 24V power adapter.
- ❺ **GND:** Connect the housing to the ground.
- ❻ **INPUT PORTS (1-16):** HDMI input ports, connect to HDMI source device such as DVD or set-top box with an HDMI cable.
- ❼ **OUTPUT PORTS (1-16):** HDMI output ports, connect to HDMI display device such as TV or monitor with an HDMI cable.

## REMOTE CONTROL



**1 POWER ON OR STANDBY:** Power on the Matrix or set it to standby mode.

**2 INPUT 1/2/3/4/5/6/7/8/9/10/11/12/13/14/15/16:** Select input source button.

**3 OUTPUT 1/2/3/4/5/6/7/8/9/10/11/12/13/14/15/16:** Select output source button.

**4 ALL:** Select all output sources simultaneously.

**For example:** when you press input “1” button and then press the “All” button, at this time the input “1” source will be output to all display devices.

### OPERATION INSTRUCTIONS:

You need to press the input button firstly and then press output button.

**For example:** Press Input-Y (Y means input button from 1 to 16)

Then press Output-X (X means output button from 1 to 16, including “All” button)

## IR CODES

CUSTOM CODE: 08F7

POWER	08F7	4D	INPUT 13	08F7	55	OUTPUT 10	08F7	44
INPUT 1	08F7	09	INPUT 14	08F7	57	OUTPUT 11	08F7	50
INPUT 2	08F7	54	INPUT 15	08F7	4E	OUTPUT 12	08F7	0E
INPUT 3	08F7	47	INPUT 16	08F7	17	OUTPUT 13	08F7	13
INPUT 4	08F7	42	OUTPUT 1	08F7	4C	OUTPUT 14	08F7	12
INPUT 5	08F7	08	OUTPUT 2	08F7	0D	OUTPUT 15	08F7	15
INPUT 6	08F7	48	OUTPUT 3	08F7	56	OUTPUT 16	08F7	53
INPUT 7	08F7	4B	OUTPUT 4	08F7	16	OUTPUT ALL	08F7	18
INPUT 8	08F7	43	OUTPUT 5	08F7	40			
INPUT 9	08F7	0C	OUTPUT 6	08F7	10			
INPUT 10	08F7	19	OUTPUT 7	08F7	11			
INPUT 11	08F7	0F	OUTPUT 8	08F7	52			
INPUT 12	08F7	03	OUTPUT 9	08F7	4F			

## SERIAL PORT PROTOCOL



**BAUD RATE:** 115200  
**DATA BITS:** 8  
**STOP BITS:** 1  
**CHECK BIT:** 0

**IP PROTOCOL:**  
**TCP/IP PORT:** 8000  
**TELNET PORT:** 23

### RS-232 CONFIGURATION

RS-232 cable is a straight thru cable and not null-modem

Definition	Pin		Pin	Definition
	1		1	DCD
TX	2		2	RX
RX	3		3	TX
	4		4	DTR
GND	5		5	GND
	6		6	DSR
	7		7	RTS
	8		8	CTS
	9		9	RI





Then, open a Serial Command tool on PC to send ASCII command to control the Matrix. The ASCII command list about the product is shown as below.

## SERIAL PORT PROTOCOL

Baud rate: 115200

Data bits: 8bit

Stop bits: 1

Check bit: 0

POWER				
COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
s power z!	POWER ON/OFF THE DEVICE, Z=0~1 (Z=0 POWER OFF, Z=1 POWER ON)	s power 1!	Power on System Initializing... Initialization Finished! FW version x.xx.xx	POWER ON
r power!	GET CURRENT POWER STATE	r power!	Power ON/Power OFF	
s reboot!	REBOOT THE DEVICE	s reboot!	Reboot... System Initializing... Initialization Finished! FW version x.xx.xx	
SYSTEM SETUP				
COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
help!	LIST ALL COMMANDS	help!		
r type!	GET DEVICE MODEL	r type!	ANI-16-4K-S	
r status!	GET DEVICE CURRENT STATUS	r status!	Get the unit all status: power, beep, lock, in/out connection, video/audio crosspoint, edid, scaler, network status	
r fw version!	GET FIRMWARE VERSION	r fw version!	MCU BOOT: VX.XX.XX MCU APP: VX.XX.XX WEB GUI: VX.XX	
r link in x!	GET THE CONNECTION STATUS OF THE X INPUT PORT, X=0~16 (0=ALL)	r link in 1!	HDMI Input 1: Connect	
r link out y!	GET THE CONNECTION STATUS OF THE Y OUTPUT PORT, Y=0~16 (0=ALL)	r link out 1!	HDMI Input 1: Connect	
s reset!	RESET TO FACTORY DEFAULTS	s reset!	Reset to factory defaults System Initializing... Initialization Finished! FW version x.xx.xx	
s beep z!	ENABLE/DISABLE BUZZER FUNCTION, Z=0~1 (Z=0 BEEP OFF, Z=1 BEEP ON)	s beep 1!	BEEP ON BEEP OFF	BEEP ON
r beep!	GET BUZZER STATE	r beep!	BEEP ON BEEP OFF	
s lock z!	LOCK/UNLOCK FRONT PANEL BUTTON, Z=0~1 (Z=0 LOCK OFF, Z=1 LOCK ON)	s lock 1!	Panel Button: LOCK ON / LOCK OFF	Panel Button: LOCK OFF
r lock!	GET PANEL BUTTON LOCK STATE	r lock!	Panel Button: LOCK ON/ OFF	
s lcd on time z!	SET LCD SCREEN REMAIN ON TIME, Z=0~4 (0:OFF, 1:ALWAYS ON, 2:15S, 3:30S, 4:60S)	s lcd on time 1!	LCD ON 15 seconds	LCD ON 30 seconds
r lcd mode!	GET THE BACKLIGHT STATUS OF LCD SCREEN	r lcd mode!	LCD ALWAYS ON	

s save preset z!	SAVE SWITCH STATE BETWEEN ALL OUTPUT PORT AND THE INPUT PORT TO PRESET Z, Z=1~8	s save preset 1!	Save to Preset 1	
s recall preset z!	CALL SAVED PRESET Z SCENARIOS, Z=1~8	s recall preset 1!	Recall from Preset 1	
s clear preset z!	CLEAR STORED PRESET Z SCENARIOS, Z=1~8	s clear preset 1!	Clear Preset 1	
r preset z!	GET PRESET Z INFORMATION, Z=1~8	r preset 1!	Video/Audio Crosspoint	
<b>OUTPUT SETTING</b>				
COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
s in x av out y!	SET INPUT X TO OUTPUT Y, X=1~16, Y=0~16 (0=ALL)	s in 1 av out 2!	INPUT 1 -> OUTPUT 2	PTP
r av out y!	GET OUTPUT Y SIGNAL STATUS Y=0~16 (0=ALL)	r av out 0!	INPUT 1 -> OUTPUT 1 ..... INPUT 16 -> OUTPUT 16	
s hdmi y stream z!	SET OUTPUT Y STREAM ON/OFF, Y=0~16 (0=ALL) Z=0~1 (0:DISABLE, 1:ENABLE)	s hdmi 1 stream 1! s hdmi 0 stream 1!	Enable HDMI Output 1 stream Disable HDMI Output 1 stream Enable HDMI all outputs stream Disable HDMI all outputs stream	ENABLE
r hdmi y stream!	GET OUTPUT Y STREAM STATUS, Y=0~16 (0=ALL)	r hdmi 1 stream!	Enable HDMI Output 1 stream	
s hdmi y scaler z!	SET HDMI OUTPUT Y PORT OUTPUT SCALER MODE, Y=0~16 (0=ALL), Z=1~3 (1=BYPASS, 2=4K->1080P, 3=AUTO)	s hdmi 1 scaler 1! s hdmi 0 scaler 1!	HDMI Output 1 set to bypass mode HDMI ALL Outputs set to bypass mode	HDMI ALL OUTPUTS SET TO BYPASS MODE
r hdmi y scaler!	GET HDMI OUTPUT Y PORT OUTPUT MODE Y=0~16 (0=ALL)	r hdmi 1 scaler !	HDMI Output 1 set to bypass mode	
s edid in x from z!	SET INPUT X EDID FROM DEFAULT EDID Z, X=0~16 (0=ALL), Z=1~39 1. 1080P, STEREO AUDIO 2.0 2. 1080P, DOLBY/DTS 5.1 3. 1080P, HD AUDIO 7.1 4. 1080I, STEREO AUDIO 2.0 5. 1080I, DOLBY/DTS 5.1 6. 1080I, HD AUDIO 7.1 7. 3D, STEREO AUDIO 2.0 8. 3D, DOLBY/DTS 5.1 9. 3D, HD AUDIO 7.1 10. 4K2K30_444,STEREO AUDIO 2.0 11. 4K2K30_444,DOLBY/DTS 5.1 12. 4K2K30_444,HD AUDIO 7.1 13. 4K2K60_420,STEREO AUDIO 2.0 14. 4K2K60_420,DOLBY/DTS 5.1 15. 4K2K60_420,HD AUDIO 7.1 16. 4K2K60_444,STEREO AUDIO 2.0 17. 4K2K60_444,DOLBY/DTS 5.1 18. 4K2K60_444,HD AUDIO 7.1 19. 4K2K60_444,STEREO AUDIO 2.0 HDR 20. 4K2K60_444,DOLBY/DTS 5.1 HDR 21. 4K2K60_444,HD AUDIO 7.1 HDR 22. USER1 23. USER2 24. COPY FROM HDMI OUTPUT 1	s edid in 1 from 1! s edid in 0 from 1!	Input 1 EDID:1080p, Stereo Audio 2.0 ALL Inputs EDID: 1080p, Stereo Audio 2.0	1080P, STEREO AUDIO 2.0

EDID SETTING				
COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
s edid in x from z!	25. COPY FROM HDMI OUTPUT 2 26. COPY FROM HDMI OUTPUT 3 27. COPY FROM HDMI OUTPUT 4 28. COPY FROM HDMI OUTPUT 5 29. COPY FROM HDMI OUTPUT 6 30. COPY FROM HDMI OUTPUT 7 31. COPY FROM HDMI OUTPUT 8 32. COPY FROM HDMI OUTPUT 9 33. COPY FROM HDMI OUTPUT 10 34. COPY FROM HDMI OUTPUT 11 35. COPY FROM HDMI OUTPUT 12 36. COPY FROM HDMI OUTPUT 13 37. COPY FROM HDMI OUTPUT 14 38. COPY FROM HDMI OUTPUT 15 39. COPY FROM HDMI OUTPUT 16			
r edid in x!	GET EDID STATUS OF THE INPUT X, X=0~16 (0=ALL INPUT)	r edid in 0!	Input 1 EDID: K2K60_444, Stereo Audio 2.0 Input 2 EDID: K2K60_444, Stereo Audio 2.0 Input 3 EDID: K2K60_444, Stereo Audio 2.0 Input 4 EDID: K2K60_444, Stereo Audio 2.0	
r edid data hdmi y!	GET THE EDID DATA OF THE HDMI OUTPUT Y PORT, Y=1~16	r edid data hdmi 1!	EDID: 00 FF FF FF FF FF FF 00 .....	
AUDIO SETTING				
COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
s hdmi y arc z!	TURN ON/OFF ARC OF HDMI OUTPUT Y, Y=0~16 (0=ALL) Z=0~1 (Z=0, OFF, Z=1 ON)	s hdmi 1 arc 1! s hdmi 0 arc 1!	HDMI Output 1 ARC ON HDMI Output 1 ARC OFF HDMI ALL Output ARC ON HDMI ALL Output ARC OFF	
r hdmi y arc!	GET THE ARC STATE OF HDMI OUTPUT Y, Y=0~16 (0=ALL)	r hdmi 1 arc!	HDMI Output 1 ARC ON	OFF
CEC SETTING				
COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
s cec in x on!	SET INPUT X POWER ON BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 on!	Input 1 POWER ON	
s cec in x off!	SET INPUT X POWER OFF BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 off!	Input 1 POWER OFF	
s cec in x menu!	SET INPUT X OPEN MENU BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 menu!	Input 1 OPEN MENU	
s cec in x back!	SET INPUT X BACK OPERATION BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 back!	Input 1 BACK OPERATION	
s cec in x up!	SET INPUT X MENU UP OPERATION BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 up!	Input 1 MENU UP OPERATION	
s cec in x down!	SET INPUT X MENU DOWN OPERATION BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 down!	Input 1 MENU DOWN OPERATION	
s cec in x left!	SET INPUT X MENU LEFT OPERATION BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 left!	Input 1 MENU LEFT OPERATION	

COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
s cec in x right!	SET INPUT X MENU RIGHT OPERATION BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 right!	Input 1 MENU RIGHT OPERATION	
s cec in x enter!	SET INPUT X MENU ENTER BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 enter!	Input 1 MENU ENTER OPERATION	
s cec in x play!	SET INPUT X PLAY BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 play!	Input 1 PLAY OPERATION	
s cec in x pause!	SET INPUT X PAUSE BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 pause!	Input 1 PAUSE OPERATION	
s cec in x stop!	SET INPUT X STOP BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 stop!	Input 1 STOP OPERATION	
s cec in x rew!	SET INPUT X REWIND BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 rew!	Input 1 REWIND OPERATION	
s cec in x mute!	SET INPUT X VOLUME MUTE BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 mute!	Input 1 VOLUME MUTE	
s cec in x vol-!	SET INPUT X VOLUME DOWN BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 vol-!	Input 1 VOLUME DOWN	
s cec in x vol+!	SET INPUT X VOLUME UP BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 vol+!	Input 1 VOLUME UP	
s cec in x ffl!	SET INPUT X FAST FORWARD BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 ffl!	Input 1 FAST FORWARD OPERATION	
s cec in x previous!	SET INPUT X PREVIOUS BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 previous!	Input 1 PREVIOUS OPERATION	
s cec in x next!	SET INPUT X NEXT BY CEC, X=0~16 (0=ALL INPUT)	s cec in 1 next!	Input 1 NEXT OPERATION	
s cec hdmi out y on!	SET HDMI OUTPUT Y POWER ON BY CEC, Y=0~16 (0=ALL OUTPUT)	s cec hdmi out 1 on!	HDMI Output 1 POWER ON	
s cec hdmi out y off	SET HDMI OUTPUT Y POWER OFF BY CEC, Y=0~16 (0=ALL OUTPUT)	s cec hdmi out 1 on!	HDMI Output 1 POWER OFF	
s cec hdmi out y mute!	SET HDMI OUTPUT Y VOLUME MUTE BY CEC, Y=0~16 (0=ALL OUTPUT)	s cec hdmi out 1 mute!	HDMI Output 1 VOLUME MUTE	
s cec hdmi out y vol-!	SET HDMI OUTPUT Y VOLUME DOWN BY CEC, Y=0~16 (0=ALL OUTPUT)	s cec hdmi out 1 vol-!	HDMI Output 1 VOLUME DOWN	
s cec hdmi out y vol+!	SET HDMI OUTPUT Y VOLUME UP BY CEC, Y=0~16 (0=ALL OUTPUT)	s cec hdmi out 1 vol+!	HDMI Output 1 VOLUME UP	
s cec hdmi out y active!	SET HDMI OUTPUT Y ACTIVE SOURCE BY CEC, Y=0~16 (0=ALL OUTPUT)	s cec hdmi out 1 active!	HDMI Output 1 ACTIVE SOURCE	

## NETWORK SETTING

COMMAND CODE	DESCRIPTION	EXAMPLE	FEEDBACK	DEFAULT SETTING
r ipconfig!	GET THE CURRENT IP CONFIGURATION	ipconfig!	IP Mode: Static IP: 192.168.1.72 Subnet Mask: 255.255.255.0 Gateway: 192.168.1.1 TCP/IP port= 8000 Telnet port= 10 Mac address: 00:1C:91:03:80:01	
r mac addr!	GET NETWORK MAC ADDRESS	r mac addr!	MAC ADDRESS: 00:1C:91:03:80:01	

s ip mode z!	SET NETWORK IP MODE TO STATIC IP OR DHCP, Z=0~1 (Z=0 STATIC, Z=1 DHCP )	s ip mode 0!	Set IP mode: Static (Please use "s net reboot!" command or repower device to apply new config!)	
r ip mode!	GET NETWORK IP MODE	r ip mode!	IP Mode: Static	
s ip addr xxx.xxx.xxx.xxx!	SET NETWORK IP ADDRESS	s ip addr 192.168.1.100!	Set IP address: 192.168.1.100 (Please use "s net reboot!" command or repower device to apply new config!) DHCP ON, Device can't config static address, set DHCP off first.	
r ip addr!	GET NETWORK IP ADDRESS	r ip addr!	IP address: r ip addr! 192.168.1.100	
s subnet xxx.xxx.xxx.xxx!	SET NETWORK SUBNET MASK	s subnet 255.255.255.0!	Set Subnet Mask: 255.255.255.0 (Please use "s net reboot!" command or repower device to apply new config!) DHCP ON, Device can't config subnet mask, set DHCP off first.	
r subnet!	GET NETWORK SUBNET MASK	r subnet!	Subnet Mask: 255.255.255.0	
s gateway xxx.xxx.xxx.xxx!	SET NETWORK GATEWAY	s gateway 192.168.1.1!	Set gateway: 192.168.1.1 Please use "s net reboot!" command or repower device to apply new config! DHCP ON, Device can't config gateway, set DHCP off first.	
r gateway!	GET NETWORK GATEWAY	r gateway!	Gateway:192.168.1.1	
s tcp/ip port x!	SET NETWORK TCP/IP PORT (X=1~65535)	s tcp/ip port 8000!	Set TCP/IP port: 8000	
r tcp/ip port!	GET NETWORK TCP/IP PORT	r tcp/ip port!	TCP/IP port: 8000	
s telnet port x!	SET NETWORK TELNET PORT (X=1~65535)	s telnet port 23!	Set Telnet Port: 23	
r telnet port!	GET NETWORK TELNET PORT	r telnet port!	Telnet Port: 23	
s net reboot!	REBOOT NETWORK MODULES	s network reboot!	Network Reboot... IP Mode: Static IP: 192.168.1.72 Subnet Mask: 255.255.255.0 Gateway: 192.168.1.1 TCP/IP Port= 8000 Telnet port= 10 Mac address: 00:1C:91:03:80:01	

## EDID MANAGEMENT

This Matrix has 21 factory defined EDID settings, 2 user-defined EDID modes and 16 copy EDID modes. You can select defined EDID mode or copy EDID mode to input port through front panel buttons, RS-232 control or Web GUI.

**On-Panel Button Operation:** On the initial OLED display screen, press “**MENU**” button to enter the EDID setting interface, press “**UP/DOWN**” button to select the required EDID, and press the “**ENTER**” button. A prompt “**copy to input :**” will appear. Then press “**UP/DOWN**” button to select the input port you need to set, and press “**ENTER**” button again to confirm this operation.

**RS-232 Control Operation:** Connect the Matrix to PC with a serial cable, then open a Serial Command tool on PC to send ASCII command “**s edid in x from z!**” to set EDID. For details, please refer to “**EDID Setting**” in the ASCII command list of “**9. RS-232 Control Command**”.

**Web GUI Operation:** Please check the EDID management in the “**Input Page**” further in this User Guide.

The defined EDID setting list of the product is shown as below:

EDID MODE	EDID DESCRIPTION
1	1080p, Stereo Audio 2.0
2	1080p, Dolby/DTS 5.1
3	1080p, HD Audio 7.1
4	1080i, Stereo Audio 2.0
5	1080i, HD Audio 7.1
6	1080i, Dolby/DTS 5.1
7	3D, Stereo Audio 2.0
8	3D, Dolby/DTS 5.1
9	3D, HD Audio 7.1
10	4K2K30_444, Stereo Audio 2.0
11	4K2K30_444, Dolby/DTS 5.1
12	4K2K30_444, HD Audio 7.1
13	4K2K60_420, Stereo Audio 2.0

EDID MODE	EDID DESCRIPTION
14	4K2K60_420, Dolby/DTS 5.1
15	4K2K60_420, HD Audio 7.1
16	4K2K60_444, Stereo Audio 2.0
17	4K2K60_444, Dolby/DTS 5.1
18	4K2K60_444, HD Audio 7.1
19	4K2K60_444, Stereo Audio 2.0 HDR
20	4K2K60_444, Dolby/DTS 5.1 HDR
21	4K2K60_444, HD Audio 7.1HDR
22	USER1
23	USER2
24	Copy from HDMI Output 1
25	Copy from HDMI Output 2
26	Copy from HDMI Output 3
27	Copy from HDMI Output 4
28	Copy from HDMI Output 5
29	Copy from HDMI Output 6
30	Copy from HDMI Output 7
31	Copy from HDMI Output 8
32	Copy from HDMI Output 9
33	Copy from HDMI Output 10
34	Copy from HDMI Output 11
35	Copy from HDMI Output 12
36	Copy from HDMI Output 13
37	Copy from HDMI Output 14
38	Copy from HDMI Output 15
39	Copy from HDMI Output 16

The Matrix can be controlled by Web GUI. The operation method is shown as below:

**STEP 1:** Get the current IP Address. The default IP address is 192.168.1.100. You can get the current Matrix IP address in two ways:

```
IP Mode: DHCP
IP:192.168.62.100
Subnet Mask:255.255.255.0
Gateway:192.168.62.1
TCP/IP port=8000
Telnet port=23
Mac address:6C:DF:FB:03:FB:6F
```


**THE FIRST WAY:** You can get the IP address via panel buttons. On the initial OLED display, press **"MENU"** button to enter the IP interface, then press **"UP/DOWN"** button to check the current IP address.

**THE SECOND WAY:** You can get the IP address via RS-232 control. Send the command **" r ipconfig!"** through an ASCII Command tool, then you'll get the feedback information as shown.

**IP:** 192.168.62.100 in the above figure is the IP Address of the Matrix (the IP address is variable, depending on what the specific machine returns). For the details of ASCII control, please refer to **"RS-232 Control Command"**.

**STEP 2:** Set the IP address of the PC to be in the same network segment with the Matrix.

**STEP 3:** Input the IP address of the Matrix into your browser on the PC to enter Web GUI page.



After entering the Web GUI page, there will be a Login page, as shown.

Select the Username from the list and enter the password. The default passwords are:

Username:	<b>User</b>	<b>Admin</b>
Password:	<b>user</b>	<b>admin</b>

After entering the password, click the **"LOGIN"** button and the following Status page will appear.

## STATUS PAGE



## SWITCH PAGE


You can do the following operations on the Switch page:

- ❶ **OUTPUT:** The current device's OUTPUT port. You can select signal source for it.
- ❷ **ALL OUTPUT:** All OUTPUT ports for the current device. You can select signal source for them.
- ❸ **INPUT:** You can click the drop-down menu to select signal source for the corresponding OUTPUT port .
- ❹ **PRESETS NAME:** You can name the current scene with maximum length of 12 characters (Chinese name is unsupported).
- ❺ **PRESETS SET:** You can restore the settings of the last saved audio-video matrix switching relationship.
- ❻ **PRESETS SAVE:** You can save audio-video matrix switching relationship.
- ❼ **PRESETS CLEAR:** You can clear the saved audio-video matrix switching relationship.

## INPUT PAGE


You can do the following operations on the Input page:

- ❶ **INPUTS:** Input channel of the device.
- ❷ **ACTIVE:** It indicates whether the channel is connected to a signal source.
- ❸ **NAME:** The input channel's name. You can modify it by entering the corresponding name (max length: 12 characters) in the input box (Chinese name is unsupported).
- ❹ **EDID:** You can set the current channel's EDID. The specific operation is as follows:



#### Set EDID for the User:

Click the “**Browse**” button, then select the bin file. If you select the wrong EDID file, there will be a prompt, as shown in the following figure.



Make sure to select the correct file, then you can check the name of the selected file. Select “**User 1**” or “**User 2**”, then click “**Upload**”. After successful setting, it will prompt as follows.

#### Download the EDID File of the Corresponding Input Channel:

Click the drop-down box of “**Select EDID File**” to select the corresponding input channel. Then click “**Download**” to download the corresponding EDID file.

## OUTPUT PAGE

You can do the following operations on the Output page:

- ❶ **OUTPUTS:** Output channel of the device.
- ❷ **NAME:** The current output channel's name. You can modify it by entering the corresponding name (max length: 12 characters) in the input box.
- ❸ **CABLE:** It indicates the connection status of output ports. When the output port is connected to the display, it shows green, otherwise, it shows gray.

④ **SCALAR MODE:** Set the current output resolution mode.

⑤ **ARC:** Turn on/off the ARC function.

⑥ **STREAM:** Turn on/off the output stream.

## CEC PAGE

You can perform CEC management on this page:

① **INPUT CONTROL:** You can control the operation of each input source by clicking the icons on the page.

② **OUTPUT CONTROL:** You can control the operation of each display, such as power on/off, volume +/-, active source switching.

## NETWORK PAGE

### Set the Default Network:

Click “**Set Network Defaults**”, there will be a prompt, as shown in the following figure.

Click “OK” to search the IP Address again, as shown in the following figure.

After searching is completed, it will switch to the login page, the default network setting is completed.

#### Modify Username:

Click the “User” button, enter the correct Old Password, New Password, and Confirm Password, then click “Save”. After successful modification, there will be a prompt, as shown in the following figure.

**NOTE:** Input rules for changing passwords:

1. The password can't be empty.
2. New Password can't be the same as Old Password.
3. New Password and Confirm Password must be the same.

#### Modify Network Setting:

Modify the Mode/IP Address/Gateway/Subnet Mask/Telnet Port as required, click “Save” to save the settings, then it will come into effect.

After modification, if the Mode is “Static”, it will switch to the corresponding IP Address; if the Mode is “DHCP”, it will automatically search and switch to the IP Address assigned by the router.

**NOTE:** Setting Telnet port to “0” disables any Telnet access.

## SYSTEM PAGE

❶ **PANEL LOCK:** Click “**Panel Lock**” to lock/unlock panel buttons. “**On**” indicates that panel buttons are unavailable; “**Off**” indicates panel buttons are available.

❷ **BEEP:** Click “**Beep**” to turn on/off the beep.

❸ **LCD:** You can turn on/off the LCD, and set the turn-on time (15s/30s/60s).


❹ **SERIAL BAUD RATE:** Click the value to set the Serial Baud Rate.

❺ **FIRMWARE UPDATE:** Click “**Browse**” to select the update file, then click “**Update**” to complete firmware update.

❻ **FACTORY RESET:** You can reset the unit to factory defaults by clicking “**Reset**”.

❼ **REBOOT:** You can reboot the unit by clicking “**Reboot**”.

**NOTE:** After reset/reboot, it will switch to the login page.





PLEASE READ THE FOLLOWING TERMS AND CONDITIONS CAREFULLY BEFORE USING THIS HARDWARE, COMPONENTS AND SOFTWARE PROVIDED BY, THROUGH OR UNDER A-NeuVideo, INC (COLLECTIVELY, THE "PRODUCT"). By using installing or using the Product, you unconditionally signify your agreement to these Terms and Conditions. If you do not agree to these Terms and Conditions, do not use the Product and return the Product to A-NeuVideo, Inc. at the return address set forth on the Product's packing label at your expense. A-NeuVideo, Inc. may modify these Terms and Conditions at anytime, without notice to you.

#### **RESTRICTIONS ON USE OF THE PRODUCT**

It is your responsibility to read and understand the installation and operation instructions, both verbal and in writing, provided to you with respect to the Product. You are authorized to use the Product solely in connection with such instructions. Any use of the Product not in accordance with such instructions shall void any warranty pertaining to the Product. Any and all damages that may occur in the use of the Product that is not strictly in accordance with such instructions shall be borne by you and you agree to indemnify and hold harmless A-NeuVideo, Inc. from and against any such damage.

The Product is protected by certain intellectual property rights owned by or licensed to A-NeuVideo. Any intellectual property rights pertaining to the Product are licensed to you by A-NeuVideo, Inc. and/or its affiliates, including any manufacturers or distributors of the Product (collectively, "A-NeuVideo") for your personal use only, provided that you do not change or delete any proprietary notices that may be provided with respect to the Product.

The Product is sold to you and any use of any associated intellectual property is deemed to be licensed to you by A-NeuVideo for your personal use only. A-NeuVideo does not transfer either the title or the intellectual property rights to the Product and A-NeuVideo retains full and complete title to the intellectual property rights therein. All trademarks and logos are owned by A-NeuVideo or its licensors and providers of the Product, and you may not copy or use them in any manner without the prior written consent of A-NeuVideo, which consent may be withheld at the sole discretion of A-NeuVideo.

The functionality and usability of the Product is controlled by A-NeuVideo, Inc. from its offices within the State of Texas, United States of America. A-NeuVideo makes no representation that materials pertaining to the Product are appropriate or available for use in other locations other than the shipping address you provided with respect thereto. You are advised that the Product may be subject to U.S. export controls.

#### **DISCLAIMERS AND LIMITATION OF LIABILITY**

A-NeuVideo may change or modify the Product at any time, from time to time.

THE PRODUCT IS PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND EITHER EXPRESS OR IMPLIED. A-NEUVIDEO DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE PRODUCT'S CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE.

A-NeuVideo has no duty or policy to update any information or statements pertaining to the Product and, therefore, such information or statements should not be relied upon as being current as of the date you use the Product. Moreover, any portion of the materials pertaining to the Product may include technical inaccuracies or typographical errors. Changes may be made from time to time without notice with respect to the Product.

TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, A-NEUVIDEO DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. A-NEUVIDEO DOES NOT WARRANT THE ACCURACY, COMPLETENESS OR USEFULNESS OF ANY INFORMATION WITH RESPECT TO THE PRODUCT. A-NEUVIDEO DOES NOT WARRANT THAT THE FUNCTIONS PERTAINING TO THE PRODUCT WILL BE ERROR-FREE, THAT DEFECTS WITH RESPECT TO THE PRODUCT WILL BE CORRECTED, OR THAT THE MATERIALS PERTAINING THERETO ARE FREE OF DEFECTS OR OTHER HARMFUL COMPONENTS. A-NEUVIDEO WILL USE ITS REASONABLE EFFORTS TO CORRECT ANY DEFECTS IN THE PRODUCT UPON TIMELY WRITTEN NOTICE FROM YOU NOT TO EXCEED 10 BUSINESS DAYS AFTER RECEIPT BY YOU OF THE PRODUCT, BUT YOU (AND NOT A-NEUVIDEO) ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR AND CORRECTION THAT WAS CAUSED BY YOU UNLESS OTHERWISE AGREED TO IN A SEPARATE WRITING BY A-NEUVIDEO.

UNDER NO CIRCUMSTANCES, INCLUDING, BUT NOT LIMITED TO, NEGLIGENCE, SHALL A-NEUVIDEO BE LIABLE FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES THAT RESULT FROM THE USE OF, OR THE INABILITY TO USE THE PRODUCT IN ACCORDANCE WITH ITS SPECIFICATIONS, EVEN IF A-NEUVIDEO OR ITS REPRESENTATIVES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL A-NEUVIDEO'S TOTAL LIABILITY TO YOU FROM ALL DAMAGES, LOSSES, AND CAUSES OF ACTION (WHETHER IN CONTRACT, OR OTHERWISE) EXCEED THE AMOUNT YOU PAID TO A-NEUVIDEO, IF ANY, FOR THE PRODUCT.