



Scan to see website

T-IN2-REC2, T-IN4-REC2, T-IN6-REC2

Quick Start Guide

This guide helps you install and use your T-IN2-REC2, T-IN4-REC2, T-IN6-REC2 for the first time.

Go to <u>www.kramerav.com/downloads/T-IN2-REC2</u>, <u>www.kramerav.com/downloads/T-IN4-REC2</u> & <u>www.kramerav.com/downloads/T-IN6-REC2</u> to download the latest user manual and check if firmware upgrades are available.

Step 1: Check What's in the Box

Ø

U The color of the sheet metal box, locking device, and magnet frame are supplied in the same color as selected for the TBUS.

- Enclosure sheet metal box (identical to selected TBUS color)
- Black/White locking device (identical to selected TBUS color)
- Magnet frame (according to the requested TBUS color)
 Cutout template



For White or Aluminum frame and/or White locking device, order separately frame and locking device accordingly.

Step 2: Table Cutout Dimensions

- T-IN2-REC2 134 X 89mm (5.28" x 3.5")
- T-IN4-REC2 234 X 89mm (9.21" x 3.5")
- T-IN6-REC2 334 X 89mm (13.15" x 3.5")

Kramer recommends using the cutout template (packed with device) and a hole saw for maximal accuracy.





Step 3: Remove Outer Frame

Remove the magnet frame and place it aside.



Step 4: Place Enclosure – Fasten Screws

- 1. Tighten screws until the frame is tightly clamped to the table.
- Fit to standard table thickness between 10-50 mm (0.39" - 1.97").



Step 5: Slide Modules

Some modules are missing grooves - please follow the comments in the 'Modules list'.

Locking device should be placed on narrow slides as shown below.





* Modules listed in Modules List section

Step 6: Lock Module

- 1. Lift the cover plate and place locking device in position.
- Lock the modules by turning Locking device mechanism a quarter turn (full turn 360°, half turn 180°, 90° does the job).
- 3. Place back the cover plate.



Step 7: Place Outer Frame

Place the magnet frame in position.





