# KRAMER





## **RTBUS-4C Quick Start Guide**

This guide helps you install and use your RTBUS-4C for the first time.


Go to <u>www.kramerav.com/downloads/RTBUS-4C</u> to download the latest user manual and check if firmware upgrades are available.


### Step 1: Check what's in the box

- ☑ 1 RTBUS-4C Round Table Mount 4 Cable Pass-Through ☑ 1 Quick start guide
- I Locking screw for locking ring

#### Step 2: Get to know your RTBUS-4C

#	Feature	
1	Enclosure	
2	Locking Ring	
3	Inner Plate	
4	Cable Slot	
5	Inner Plate Screws (4)	
6	Cable Bushings	
	· ·	X












P/N: 2900-301469QS

#### Step 3: Mount RTBUS-4C

To mount RTBUS-4C:

- 1. Cut a hole in the table 115mm in diameter.
- 2. Remove the four inner plate screws and remove the inner plate from the enclosure.
- 3. Run the cables under the table, through the locking ring, and up through the hole in the table.
- 4. Remove the bushings from their slots.
- 5. Insert the cables into the bushings on the slots of the inner plate.
- 6. Replace the bushings in the slots.
- 7. Place the inner plate into the enclosure and secure the four screws.
- 8. Place the enclosure into the hole in the table and secure it with the locking ring.
- 9. Secure the locking ring with the locking ring screw.



#### **Technical Specifications**

Compatibility	Maximum Cable Diameter	8mm
	Minimum Strain Relief Width	9mm
Physical	Enclosure & Locking Ring Material	Aluminum
	Inner Plate Material	Steel
	Cutout Dimensions	115mm Ø
	Weight	0.55kg

Specifications are subject to change without notice at www.kramerav.com

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

