


4K60 Modular Matrix Switcher

—With TV Wall Function



Chassis Selection 1: MINI-MANAGER Series

Modular Chassis

Buttons with Light

2-key fast switch

APP/WEB GUI

Dual RS232

- 9x9, 18x18 and 36x36 chassis
- Seamless switching
- 4K60Hz, HDCP2.2, HDMI2.0
- All types I/O cards for selection
- 1 card 1-port



Input and output card

4K60 HDMI Input Card



- 1 card 1 HDMI Input
- 4K60, HDCP2.2, HDMI2.0 444, HDR
- 3.5 mm audio embedded
- Seamless switching

4K60 HDMI Output Card



- 1 card 1 HDMI output
- 4K60, HDCP2.2, HDMI2.0 444, HDR
- 3.5 mm audio de-embedded
- Seamless switching

WEB Control

Matrix Manager **Switch** Scene Caption Setup Logout More ▾

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18		


1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18		

-
-
-
-

x: y:

X	X	X	X
X	X	X	X
X	X	X	X

WEB Control Operation Steps






Step 1: Type the IP address here

A login form titled "Please login" is shown. It contains two input fields: the first is labeled "admin" and the second is filled with six dots. Below these fields is a blue button labeled "Login". The entire form is enclosed in a red rectangular box, with a red arrow pointing from the text "Step 2: Enter the user name and password, Click to Login" to the bottom of the box.

Step 2: Enter the user name and password,
Click to Login

WEB Control Operation Steps



TV Wall set up

x: y:



Delete the TV Wall




Set up a 3x4 TV Wall

Function shortcut buttons

WEB Control Operation Steps







x: 3 y: 4 add del



Step 4: Drag the outputs down to the TV Wall



WEB Control Operation Steps



Step 5: Drag the corresponded outputs to the TV Wall until it's all full filled

3x4 TV Wall

WEB Control Operation Steps



WEB Control Operation Steps

