

KRAMER ELECTRONICS LTD.

USER MANUAL

MODEL:

102MX

2 Channel Audio Mixer

P/N: 2900-901020 Rev 2



102MX Quick Start Guide


This guide helps you install and use your product for the first time. For more detailed information, go to http://www.kramerelectronics.com/support/product_downloads.asp to download the latest manual or scan the QR code on the left.

Step 1: Check what's in the box



102MX 2 Channel Audio Mixer 1 Power supply (12V DC)






Save the original box and packaging materials in case you need to return your 102MX for service.

Step 2: Install the 102MX

Attach the rubber feet and place on a table or mount the 102MX in a rack (using an optional RK-T3 rack mount).


Step 3: Connect the inputs and outputs

Always switch off the power on each device before connecting it to your 102MX.



Always use Kramer high-performance cables for connecting AV equipment to the 102MX.

Step 4: Connect the power





Step 5: Operate the 102MX

Use the buttons to set the type of input, the type of mic (if used) and talk-over. Use the knobs to adjust the mic, line or master levels.

Contents

1	Introduction	1
2 2.1 2.2	Getting Started Achieving the Best Performance Recycling Kramer Products	2 2 3
3 3.1	Overview Defining the 102MX 2 Channel Audio Mixer	2
4	Connecting the 102MX	6
5 5.1 5.2 5.3 5.4 6	Operating the 102MX Choosing the Microphone Type Using a Microphone Using the Talk-Over Function Using the Volume Controls Technical Specifications	7 7 7 7 8
Figu	ures	
	e 1: 102MX 2 Channel Audio Mixer	5

102MX - Contents

1 Introduction

Welcome to Kramer Electronics! Since 1981, Kramer Electronics has been providing a world of unique, creative, and affordable solutions to the vast range of problems that confront video, audio, presentation, and broadcasting professionals on a daily basis. In recent years, we have redesigned and upgraded most of our line, making the best even better!

Our 1,000-plus different models now appear in 11 groups that are clearly defined by function: GROUP 1: Distribution Amplifiers; GROUP 2: Switchers and Routers; GROUP 3: Control Systems; GROUP 4: Format/Standards Converters; GROUP 5: Range Extenders and Repeaters; GROUP 6: Specialty AV; GROUP 7: Scan Converters and Scalers; GROUP 8: Cables and Connectors; GROUP 9: Room Connectivity; GROUP 10: Accessories and Rack Adapters and GROUP 11: Sierra.

Congratulations on purchasing your Kramer **102MX** 2 *Channel Audio Mixer*, which is ideal for the following typical applications:

- Small audio studio applications
- Presentation applications for microphone/line mixing simultaneously

102MX - Introduction

2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
- Review the contents of this user manual
- Use Kramer high-performance, high-resolution cables



Go to http://www.kramerelectronics.com to check for up-to-date user manuals, application programs, and to check if firmware upgrades are available (where appropriate).

2.1 Achieving the Best Performance

To achieve the best performance:

- Use only good quality connection cables to avoid interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables)
- Do not secure the cables in tight bundles or roll the slack into tight coils
- Avoid interference from neighboring electrical appliances that may adversely influence signal quality
- Position your Kramer 102MX away from moisture, excessive sunlight and dust

Caution: No operator serviceable parts inside the unit

Warning: Use only the Kramer Electronics input power wall

adapter that is provided with the unit

Warning: Disconnect the power and unplug the unit from the wall

before installing

2.2 Recycling Kramer Products

The Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC aims to reduce the amount of WEEE sent for disposal to landfill or incineration by requiring it to be collected and recycled. To comply with the WEEE Directive, Kramer Electronics has made arrangements with the European Advanced Recycling Network (EARN) and will cover any costs of treatment, recycling and recovery of waste Kramer Electronics branded equipment on arrival at the EARN facility. For details of Kramer's recycling arrangements in your particular country go to our recycling pages at http://www.kramerelectronics.com/support/recycling/.

3 Overview

The **102MX** is a high-performance 2 channel stereo audio mixer for line level and mic level audio signals. It mixes one line level input with either a microphone or a second line level input and produces a mixed audio output signal.

The 102MX features:

- A selectable microphone input dynamic or condenser
- A user-enabled talk-over function that mutes the line input when the mic detects sound
- Three volume controls Mic/Line Level, Line 2 Level, Master Level
- A 12V DC power supply, included
- 3 units can be rack mounted side-by-side in a 1U rack space with the optional RK-3T rack adapter

3.1 Defining the 102MX 2 Channel Audio Mixer

This section defines the 102MX.




Figure 1: 102MX 2 Channel Audio Mixer

#	Feature	Function
1	LINE OUT (L, R) RCA Connectors	Connect to the right and left channels of a line level stereo audio acceptor
2	LINE 2 IN (L, R) RCA Connectors	Connect to the right and left channels of a line level stereo audio source
3	TALK OVER Button	Press to activate the talk-over function
4	MIC SELECT Button	Press to select the Input 1 mic level signal, release to select Input 1 line level signal
5	COND. MIC Button	Press for a powered condenser mic, release for an unpowered dynamic mic
6	MIC/LINE 1 IN 6mm Socket	Connects to a mic or line level source
7	MASTER LEVEL Knob	Controls the mixed signal output level
8	LINE 2 LEVEL Knob	Controls the line 2 input level
9	MIC/LINE1 LEVEL Knob	Controls the mic/line 1 input level and talk-over sensitivity
10	ON LED	Illuminates when the unit is ON
11	12V DC Connector	Connects to the 12V DC power supply

102MX - Overview 5

4 Connecting the 102MX



Always switch off the power to each device before connecting it to your **102MX**. After connecting your **102MX**, connect its power and then switch on the power to each device.

To connect the 102MX as illustrated in the example in Figure 2:

- 1. Connect a mic or line source to Mic/Line IN 1.
- 2. Connect a stereo audio source to Line 2 IN (such as a stereo audio player).
- Connect Line OUT to a stereo audio acceptor (such as a stereo audio recorder).
- 4. Connect the 12V DC power supply to the 102MX 12V DC socket and plug the power supply into the mains electricity. The ON LED lights.



The power supply is not shown in Figure 2.



Figure 2: Connecting the 102MX 2 Channel Audio Mixer

5 Operating the 102MX

This section explains how to operate the 102MX.

5.1 Choosing the Microphone Type

- When using a powered condenser microphone, press in the COND MIC. button
- When using an unpowered dynamic mic, release the COND MIC. button

5.2 Using a Microphone

 If you are using a microphone on MIC/LINE 1 IN, press in the MIC SELECT button to select the mic input

5.3 Using the Talk-Over Function

To use the talk-over function, press in the TALK OVER button
 The 102MX automatically inserts the mic signal and fades the source of
 LINE 2 IN. The unit becomes a fader instead of a mixer

5.4 Using the Volume Controls

- Adjust the volume of the mic or line 1 input with the MIC/LINE 1 LEVEL knob
- Adjust the volume of the line 2 input with the LINE 2 LEVEL knob
- Adjust the volume of the mixed output with the MASTER LEVEL knob

6 Technical Specifications

INPUTS:	Mic/line 1: 10mV/1.6k Ω , 1Vpp/10k Ω , on 6.5mm phone connector; Line 2: 1Vpp/10k Ω , stereo on RCA connectors	
OUTPUTS:	Line level, stereo, up to 5.6Vpp/15Ω on RCA connectors	
BANDWIDTH (-3dB):	100kHz	
GAIN RANGE:	-12dB to 68.5dB (mic); -12dB to +8.8dB (line)	
DIFF. PHASE:	0.05Deg.	
S/N RATIO:	69dB	
CONTROL:	Mic/line 1 level, line 2 level, master level rotary controls, condenser/dynamic mic, line/mic, talkover selection switches	
AUDIO THD+NOISE:	0.018%	
2nd HARMONIC:	0.002%	
POWER CONSUMPTION:	12V DC, 40mA	
OPERATING TEMPERATURE:	0° to +40°C (32° to 104°F)	
STORAGE TEMPERATURE:	-40° to +70°C (-40° to 158°F)	
HUMIDITY:	10% to 90%, RHL non-condensing	
DIMENSIONS:	12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98") W, D, H.	
WEIGHT:	0.25kg (0.55lbs) approx.	
ACCESSORIES:	Power supply, mounting bracket	
OPTIONS:	RK-3T 19" rack adapter	
Specifications are subject to change without notice at http://www.kramerelectronics.com		

LIMITED WARRANTY

The warranty obligations of Kramer Electronics for this product are limited to the terms set forth below:

What is Covered

This limited warranty covers defects in materials and workmanship in this product.

What is Not Covered

This limited warranty does not cover any damage, deterioration or malfunction resulting from any alteration, modification, improper or unreasonable use or maintenance, misuse, abuse, accident, neglect, exposure to excess moisture, fire, improper packing and shipping (such claims must be presented to the carrier), lightning, power surges, or other acts of nature. This limited warranty does not cover any damage, deterioration or malfunction resulting from the installation or removal of this product from any installation, any unauthorized tampering with this product, any repairs attempted by anyone unauthorized by Kramer Electronics to make such repairs, or any other cause which does not relate directly to a defect in materials and/or workmanship of this product. This limited warranty does not cover cartons, equipment enclosures, cables or accessories used in conjunction with this product.

Without limiting any other exclusion herein, Kramer Electronics does not warrant that the product covered hereby, including, without limitation, the technology and/or integrated circuit(s) included in the product, will not become obsolete or that such items are or will remain compatible with any other product or technology with which the product may be used.

How Long Does this Coverage Last

Seven years as of this printing; please check our Web site for the most current and accurate warranty information.

Who is Covered

Only the original purchaser of this product is covered under this limited warranty. This limited warranty is not transferable to subsequent purchasers or owners of this product.

What Kramer Electronics will do

Kramer Electronics will, at its sole option, provide one of the following three remedies to whatever extent it shall deem necessary to satisfy a proper claim under this limited warranty:

- 1. Elect to repair or facilitate the repair of any defective parts within a reasonable period of time, free of any charge for the necessary parts and labor to complete the repair and restore this product to its proper operating condition. Kramer Electronics will also pay the shipping costs necessary to return this product once the repair is complete.
- 2. Replace this product with a direct replacement or with a similar product deemed by Kramer Electronics to perform substantially the same function as the original product.
- 3. Issue a refund of the original purchase price less depreciation to be determined based on the age of the product at the time remedy is sought under this limited warranty.

What Kramer Electronics will not do Under This Limited Warranty

If this product is returned to Kramer Electronics or the authorized dealer from which it was purchased or any other party authorized to repair Kramer Electronics products, this product must be insured during shipment, with the insurance and shipping charges prepaid by you. If this product is returned uninsured, you assume all risks of loss or damage during shipment. Kramer Electronics will not be responsible for any costs related to the removal or re-installation of this product from or into any installation. Kramer Electronics will not be responsible for any costs related to any setting up this product, any adjustment of user controls or any programming required for a specific installation of this product.

Amy to Obtain a Remedy under this Limited Warranty
To obtain a remedy under this limited warranty, you must contact either the authorized Kramer Electronics reseller from whom you purchased this product or the Kramer Electronics office nearest you. For a list of authorized Kramer Electronics resellers and/or Kramer Electronics authorized service providers, please visit our web site at www.kramerelectronics.com or contact the Kramer Electronics office nearest you.

In order to pursue any remedy under this limited warranty, you must possess an original, dated receipt as proof of purchase from an authorized Kramer Electronics reseller. If this product is returned under this limited warranty, a return authorization number, obtained from Kramer Electronics, will be required. You may also be directed to an authorized reseller or a person authorized by Kramer Electronics to repair the product.

If it is decided that this product should be returned directly to Kramer Electronics, this product should be properly packed, preferably in the original carton, for shipping. Cartons not bearing a return authorization number will be refused.

Limitation on Liability

THE MAXIMUM LIABILITY OF KRAMER ELECTRONICS UNDER THIS LIMITED WARRANTY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID FOR THE PRODUCT. TO THE MAXIMUM EXTENT PERMITTED BY LAW, KRAMER ELECTRONICS IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, Some countries, districts or states do not allow the exclusion or limitation of relief, special, incidental, consequential or indirect damages, or the limitation of liability to specified amounts, so the above limitations or exclusions may not apply to you.

Exclusive Remedy

TO THE MAXIMUM EXTENT PERMITTED BY LAW, THIS LIMITED WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. TO THE MAXIMUM EXTENT PERMITTED BY LAW, KRAMER ELECTRONICS SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF KRAMER ELECTRONICS CANNOT LAWFULLY DISCLAIM OR EXCLUDE IMPLIED WARRANTIES UNDER APPLICABLE LAW. THEN ALL IMPLIED WARRANTIES COVERING THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL APPLY TO THIS PRODUCT AS PROVIDED UNDER APPICABLE LAW.

IF ANY PRODUCT TO WHICH THIS LIMITED WARRANTY APPLIES IS A "CONSUMER PRODUCT" UNDER THE MAGNUSON-MOSS WARRANTY ACT (15 U.S.C.A. §2301, ET SEQ.) OR OTHER APPICABLE LAW, THE FOREGOING DISCLAIMER OF IMPLIED WARRANTIES SHALL NOT APPLY TO YOU, AND ALL IMPLIED WARRANTIES ON THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR THE PARTICULAR PURPOSE, SHALL APPLY AS PROVIDED UNDER APPLICABLE LAW.

Other Conditions

This limited warranty gives you specific legal rights, and you may have other rights which vary from country to country or state to

This limited warranty is void if (i) the label bearing the serial number of this product has been removed or defaced, (ii) the product is not distributed by Kramer Electronics or (iii) this product is not purchased from an authorized Kramer Electronics reseller. If you are unsure whether a reseller is an authorized Kramer Electronics reseller, please visit our Web site at www.kramerelectronics.com or contact a Kramer Electronics office from the list at the end of this document.

Your rights under this limited warranty are not diminished if you do not complete and return the product registration form or complete and submit the online product registration form. Kramer Electronics thanks you for purchasing a Kramer Electronics product. We hope it will give you years of satisfaction.



For the latest information on our **102MX** and a list of Kramer distributors, visit our Web site where updates to this user manual may be found.

We welcome your questions, comments, and feedback.

Web site: www.kramerelectronics.com

E-mail: info@kramerel.com







SAFETY WARNING

Disconnect the unit from the power supply before opening and servicing



2/NI: 200

2900-901020